



FCAR F3 Diagnositic list (note: for reference only)

Automaker: Hyundai
version info: V5.6

Model	Model	Year	System	System	System	Function					
						Version information	Read DTC	Clear DTC	Read data stream	Action test	Remark (other functions)
AeroBus		2011	D6CB(L-ENG)	Engine	D6CB(L-ENG)	√	√	√	√	√	-
				ETACS	ETACS	√	-	-	√	-	-
				DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG		√	-	-	√	-	-	
			D6CA(L-ENG)	Engine	D6CA(L-ENG)	√	√	√	√	√	-
				ETACS	ETACS	√	-	-	√	-	-
		D6AB	Engine	D6AB	√	√	√	√	√	-	
			ETACS	ETACS	√	-	-	√	-	-	
		2010	D6CB(L-ENG)	Engine	D6CB(L-ENG)	√	√	√	√	√	-
				ETACS	ETACS	√	-	-	√	-	-
				DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG		√	-	-	√	-	-	
			D6CA	Engine	D6CA	√	√	√	√	√	-
				ETACS	ETACS	√	-	-	√	-	-
		D6AB	Engine	D6AB	√	√	√	√	√	-	
			ETACS	ETACS	√	-	-	√	-	-	
		2009	D6CB	Engine	D6CB	√	√	√	√	√	-
				ETACS	ETACS	√	-	-	√	-	-
				DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG		√	-	-	√	-	-	
			D6CA	Engine	D6CA	√	√	√	√	√	-
				ETACS	ETACS	√	-	-	√	-	-
		D6AB	Engine	D6AB	√	√	√	√	√	-	
			ETACS	ETACS	√	-	-	√	-	-	
		2008	D6CB	Engine	D6CB	√	√	√	√	√	-
				ETACS	ETACS	√	-	-	√	-	-
				DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG		√	-	-	√	-	-	
			D6CA	Engine	D6CA	√	√	√	√	√	-
				ETACS	ETACS	√	-	-	√	-	-
D6AB	Engine	D6AB	√	√	√	√	√	-			
	ETACS	ETACS	√	-	-	√	-	-			
D6CB	Engine	D6CB	√	√	√	√	√	-			
	ETACS	ETACS	√	-	-	√	-	-			

2007	D6CD	DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
			DTG	✓	-	-	✓	-	-	
	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
	2006	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-
			ETACS	ETACS	✓	-	-	✓	-	-
		D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-
			ETACS	ETACS	✓	-	-	✓	-	-
	2005	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-
			ETACS	ETACS	✓	-	-	✓	-	-
D6AB		Engine	D6AB	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
2004	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
2003	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
2002	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
2001	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
2000	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
1999	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
2011	D6CC (L-ENG)	Engine	D6CC (L-ENG)	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
			DTG	✓	-	-	✓	-	-	
	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
			DTG	✓	-	-	✓	-	-	
	C6AE (Q-CNG)	Engine	C6AE (Q-CNG)	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
			DTG	✓	✓	✓	✓	-	-	

AeroBus (KOR)

		DTG/DIS	DTG	✓	-	-	✓	-	-
2010	D6CC (L-ENG)	Engine	D6CC (L-ENG)	✓	✓	✓	✓	✓	-
		BCM	BCM	✓	✓	✓	✓	✓	-
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
			DTG	✓	-	-	✓	-	-
	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-
		BCM	BCM	✓	✓	✓	✓	✓	-
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
			DTG	✓	-	-	✓	-	-
	C6AE (Q-CNG)	Engine	C6AE (Q-CNG)	✓	✓	✓	✓	✓	-
		BCM	BCM	✓	✓	✓	✓	✓	-
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
			DTG	✓	-	-	✓	-	-
2009	D6CC (L-ENG)	Engine	D6CC (L-ENG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
			DTG	✓	-	-	✓	-	-
	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
			DTG	✓	-	-	✓	-	-
2008	D6CC (L-ENG)	Engine	D6CC (L-ENG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
			DTG	✓	-	-	✓	-	-
	D6CB (L-ENG)	Engine	D6CB (L-ENG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
			DTG	✓	-	-	✓	-	-
	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
			DTG	✓	-	-	✓	-	-
2007	D6CB (L-ENG)	Engine	D6CB (L-ENG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
			DTG	✓	-	-	✓	-	-
	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-

		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
2006	D6CB (L-ENG)	Engine	D6CB (L-ENG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
	D6AB (Q-DD ENG)	Engine	D6AB (Q-DD ENG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
2005	D6CB (L-ENG)	Engine	D6CB (L-ENG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
	D6AB (Q-DD ENG)	Engine	D6AB (Q-DD ENG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
2004	D6CB (L-ENG)	Engine	D6CB (L-ENG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
	D6CA (L-ENG)	Engine	D6CA (L-ENG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
	D6AB (Q-DD ENG)	Engine	D6AB (Q-DD ENG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
2003	D6CA (L-ENG)	Engine	D6CA (L-ENG)	✓	✓	✓	✓	✓	-
	D6AB (Q-DD ENG)	Engine	D6AB (Q-DD ENG)	✓	✓	✓	✓	✓	-
2002	D6CA (L-ENG)	Engine	D6CA (L-ENG)	✓	✓	✓	✓	✓	-
	D6AB (Q-DD ENG)	Engine	D6AB	✓	✓	✓	✓	✓	-
2001	D6CA (L-ENG)	Engine	D6CA (L-ENG)	✓	✓	✓	✓	✓	-
	D6AB (Q-DD ENG)	Engine	D6AB (Q-DD ENG)	✓	✓	✓	✓	✓	-
2000	D6CA (L-ENG)	Engine	D6CA (L-ENG)	✓	✓	✓	✓	✓	-
	D6AB (Q-DD ENG)	Engine	D6AB (Q-DD ENG)	✓	✓	✓	✓	✓	-
1999	D6AB (Q-DD ENG)	Engine	D6AB (Q-DD ENG)	✓	✓	✓	✓	✓	-
2011	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-
	D6HA (H-ENG)	Engine	D6HA (H-ENG)	✓	✓	✓	✓	✓	-
		AT	ZF ECOMAT4	✓	✓	✓	✓	-	-
			ZF ECOMAT2	✓	✓	✓	✓	-	-
		INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
	DTG		✓	-	-	✓	-	-	
	C6AE (Q-CNG)	Engine	C6AE (Q-CNG)	✓	✓	✓	✓	✓	-
		AT	ZF ECOMAT4 (5HP502)	✓	✓	✓	✓	-	-
			ZF ECOMAT2 (4HP590)	✓	✓	✓	✓	-	-
			ZF ECOLIFE	✓	✓	✓	✓	-	-
			RETARDER	RETARDER (VOICE)	✓	✓	✓	✓	✓

AeroCity	2010	D6HA (H-ENG)	ECAS	ECAS (WABCO)	√	√	√	√	√	-		
			BCM	BCM	√	√	√	√	√	-		
			DTG/DIS	DTG/DIS	√	√	√	√	-	-		
				DTG	√	-	-	√	-	-		
			Engine	D6HA (H-ENG)	√	√	√	√	√	-		
			AT	ZF ECOMAT4	√	√	√	√	-	-		
				ZF ECOMAT2 (4HP590)	√	√	√	√	-	-		
			INTARDER	ZF Intarder	√	√	√	√	√	-		
			ETACS	ETACS	√	-	-	√	-	-		
			DTG/DIS	DTG/DIS	√	√	√	√	-	-		
				DTG	√	-	-	√	-	-		
			2009	D6AB	Engine	D6AB	√	√	√	√	√	-
			2008	D6AB	Engine	D6AB	√	√	√	√	√	-
			2007	D6AB	Engine	D6AB	√	√	√	√	√	-
			2006	D6AB	Engine	D6AB	√	√	√	√	√	-
2005	D6AB	Engine	D6AB	√	√	√	√	√	-			
2004	D6AB	Engine	D6AB	√	√	√	√	√	-			
2003	D6AB	Engine	D6AB	√	√	√	√	√	-			
2002	D6AB	Engine	D6AB	√	√	√	√	√	-			
2001	D6AB	Engine	D6AB	√	√	√	√	√	-			
2000	D6AB	Engine	D6AB	√	√	√	√	√	-			
1999	D6AB	Engine	D6AB	√	√	√	√	√	-			
1998	D6AB	Engine	D6AB	√	√	√	√	√	-			
	2011	D6HA (H-ENG)	Engine	D6HA (H-ENG)	√	√	√	√	√	-		
				D6HA (H-ENG 10EM)	√	√	√	√	√	-		
			AT	ZF ECOMAT4 (5HP502)	√	√	√	√	-	-		
				ZF ECOMAT2 (4HP590)	√	√	√	√	-	-		
				ZF ECOLIFE	√	√	√	√	-	-		
			RETARDER	RETARDER (VOICE)	√	√	√	√	√	-		
			BCM	BCM	√	√	√	√	√	-		
			DTG/DIS	DTG/DIS	√	√	√	√	-	-		
				DTG	√	-	-	√	-	-		
			Engine	C6AC (Q-CNG)	√	√	√	√	√	-		
			AT	ZF ECOMAT4 (5HP502)	√	√	√	√	-	-		
				ZF ECOMAT2 (4HP590)	√	√	√	√	-	-		
				ZF ECOLIFE	√	√	√	√	-	-		
			RETARDER	RETARDER (VOICE)	√	√	√	√	√	-		
			ECAS	ECAS (WABCO)	√	√	√	√	√	-		
BCM	BCM	√	√	√	√	√	-					

AeroCity (KOR)	2010	C6AE (Q-CNG)	DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-		
				DTG	✓	-	-	✓	-	-		
			Engine	C6AE (Q-CNG)	✓	✓	✓	✓	✓	-		
				AT	ZF ECOMAT4 (5HP502)	✓	✓	✓	✓	-		
			ZF ECOMAT2 (4HP590)		✓	✓	✓	✓	-			
			ZF ECOLIFE		✓	✓	✓	✓	-			
			RETARDER	RETARDER (VOICE)	✓	✓	✓	✓	✓			
			ECAS	ECAS (WABCO)	✓	✓	✓	✓	✓			
			BCM	BCM	✓	✓	✓	✓	✓			
			DTG/DIS	DTG/DIS	✓	✓	✓	✓	-			
				DTG	✓	-	-	✓	-			
				DIS	✓	✓	✓	✓	-			
	2010	D6HA (H-ENG)	Engine	D6HA (H-ENG)	✓	✓	✓	✓	✓	-		
				D6HA (H-ENG 10EM)	✓	✓	✓	✓	✓			
			AT	ZF ECOMAT4 (5HP502)	✓	✓	✓	✓	-			
				ZF ECOMAT2 (4HP590)	✓	✓	✓	✓	-			
				ZF ECOLIFE	✓	✓	✓	✓	-			
			RETARDER	RETARDER (VOICE)	✓	✓	✓	✓	✓			
			BCM	BCM	✓	✓	✓	✓	✓			
			DTG/DIS	DTG/DIS	✓	✓	✓	✓	-			
				DTG	✓	-	-	✓	-			
			2010	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-
						AT	ZF ECOMAT4 (5HP502)	✓	✓	✓	✓	-
					ZF ECOMAT2 (4HP590)		✓	✓	✓	✓	-	
	ZF ECOLIFE	✓			✓		✓	✓	-			
	RETARDER	RETARDER (VOICE)			✓	✓	✓	✓	✓			
	ECAS	ECAS (WABCO)			✓	✓	✓	✓	✓			
	BCM	BCM			✓	✓	✓	✓	✓			
	DTG/DIS	DTG/DIS			✓	✓	✓	✓	-			
		DTG			✓	-	-	✓	-			
	2010	C6AE (Q-CNG)			Engine	C6AE (Q-CNG)	✓	✓	✓	✓	✓	-
						AT	ZF ECOMAT4 (5HP502)	✓	✓	✓	✓	-
					ZF ECOMAT2 (4HP590)		✓	✓	✓	✓	-	
ZF ECOLIFE			✓	✓	✓		✓	-				
RETARDER			RETARDER (VOICE)	✓	✓	✓	✓	✓				
ECAS			ECAS (WABCO)	✓	✓	✓	✓	✓				
BCM			BCM	✓	✓	✓	✓	✓				
DTG/DIS			DTG/DIS	✓	✓	✓	✓	-				
			DTG	✓	-	-	✓	-				

			DIS	✓	✓	✓	✓	-	-
2009	D6HA (H-ENG)	Engine	D6HA (H-ENG)	✓	✓	✓	✓	✓	-
		AT	ZF ECOMAT4 (5HP502)	✓	✓	✓	✓	-	-
			ZF ECOMAT2 (4HP590)	✓	✓	✓	✓	-	-
		RETARDER	RETARDER (VOICE)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
	DTG		✓	-	-	✓	-	-	
	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-
		AT	ZF ECOMAT4 (5HP502)	✓	✓	✓	✓	-	-
			ZF ECOMAT2 (4HP590)	✓	✓	✓	✓	-	-
		RETARDER	RETARDER (VOICE)	✓	✓	✓	✓	✓	-
		ECAS	ECAS (WABCO)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
	DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
DTG		✓	-	-	✓	-	-		
2008	D6HA (H-ENG)	Engine	D6HA (H-ENG)	✓	✓	✓	✓	✓	-
		AT	ZF ECOMAT4 (5HP502)	✓	✓	✓	✓	-	-
			ZF ECOMAT2 (4HP590)	✓	✓	✓	✓	-	-
		RETARDER	RETARDER (VOICE)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
	DTG		✓	-	-	✓	-	-	
	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-
		AT	ZF ECOMAT4 (5HP502)	✓	✓	✓	✓	-	-
			ZF ECOMAT2 (4HP590)	✓	✓	✓	✓	-	-
		RETARDER	RETARDER (VOICE)	✓	✓	✓	✓	✓	-
		ECAS	ECAS (WABCO)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
	DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
DTG		✓	-	-	✓	-	-		
2007	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
	D6AB (Q-DD ENG)	Engine	D6AB (Q-DD ENG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
2006	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-
	D6AB (Q-DD ENG)	Engine	D6AB (Q-DD ENG)	✓	✓	✓	✓	✓	-
		ETACS	ETACS	✓	-	-	✓	-	-

AeroTown	2005	D6AB(Q-DD ENG)	Engine	D6AB(Q-DD ENG)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
	2004	D6AB(Q-DD ENG)	Engine	D6AB(Q-DD ENG)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
	2003	D6AB(Q-DD ENG)	Engine	D6AB(Q-DD ENG)	√	√	√	√	√	-
	2002	D6AB(Q-DD ENG)	Engine	D6AB(Q-DD ENG)	√	√	√	√	√	-
	2001	D6AB(Q-DD ENG)	Engine	D6AB(Q-DD ENG)	√	√	√	√	√	-
	2000	D6AB(Q-DD ENG)	Engine	D6AB(Q-DD ENG)	√	√	√	√	√	-
	1999	D6AB(Q-DD ENG)	Engine	D6AB(Q-DD ENG)	√	√	√	√	√	-
	2011		ETACS	ETACS	√	-	-	√	-	-
		D6GA(G-ENG)	ETACS	ETACS	√	-	-	√	-	-
	2010	D6BR	ETACS	ETACS	√	-	-	√	-	-
		D6DA	ETACS	ETACS	√	-	-	√	-	-
	2009	D6BR	ETACS	ETACS	√	-	-	√	-	-
		D6DA	ETACS	ETACS	√	-	-	√	-	-
	2008	D6BR	ETACS	ETACS	√	-	-	√	-	-
		D6DA	ETACS	ETACS	√	-	-	√	-	-
	2007	D6BR	ETACS	ETACS	√	-	-	√	-	-
		D6DA	ETACS	ETACS	√	-	-	√	-	-
	2006	D6BR	ETACS	ETACS	√	-	-	√	-	-
		D6DA	ETACS	ETACS	√	-	-	√	-	-
	2005	D6BR	ETACS	ETACS	√	-	-	√	-	-
		D6DA	ETACS	ETACS	√	-	-	√	-	-
	2004	D6BR	ETACS	ETACS	√	-	-	√	-	-
	D6DA	ETACS	ETACS	√	-	-	√	-	-	
AeroTown (KOR)	2011	D6GA(G-ENG)	BCM	BCM	√	√	√	√	√	-
	2010	D6GA(G-ENG)	BCM	BCM	√	√	√	√	√	-
	2009	D6GA(G-ENG)	ETACS	ETACS	√	-	-	√	-	-
	2008	D6GA(G-ENG)	ETACS	ETACS	√	-	-	√	-	-
	2007	D6DA(KK-ENG)	Engine	D6DA(KK-ENG)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
	2006	D6DA(KK-ENG)	Engine	D6DA(KK-ENG)	√	√	√	√	√	-
		ETACS	ETACS	√	-	-	√	-	-	
2005	D6DA(KK-ENG)	Engine	D6DA(KK-ENG)	√	√	√	√	√	-	
		ETACS	ETACS	√	-	-	√	-	-	
	2011	D4DD	ETACS	ETACS	√	-	-	√	-	-
		D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-

Country		D4DA	ETACS	ETACS	√	-	-	√	-	-
	2010	D4DD	ETACS	ETACS	√	-	-	√	-	-
		D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
		D4DA	ETACS	ETACS	√	-	-	√	-	-
	2009	D4DD	ETACS	ETACS	√	-	-	√	-	-
		D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
		D4DA	ETACS	ETACS	√	-	-	√	-	-
	2008	D4DD	ETACS	ETACS	√	-	-	√	-	-
		D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
		D4DA	ETACS	ETACS	√	-	-	√	-	-
		D4AF	ETACS	ETACS	√	-	-	√	-	-
	2007	D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
		D4DA	ETACS	ETACS	√	-	-	√	-	-
	2006	D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
		D4DA	ETACS	ETACS	√	-	-	√	-	-
	2005	D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
		D4DA	ETACS	ETACS	√	-	-	√	-	-
	2004	D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
		D4DA	ETACS	ETACS	√	-	-	√	-	-

e- Country (KOR)	2011	D4GA (F-ENG)	ABS	ABS (HPB)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
			DTG/DIS	DTG	√	-	-	√	-	-
	2010	D4GA (F-ENG)	ABS	ABS (HPB)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
			DTG/DIS	DTG	√	-	-	√	-	-
	2009	D4GA (F-ENG)	ABS	ABS (HPB)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
			DTG/DIS	DTG	√	-	-	√	-	-
	2008	D4GA (F-ENG)	ABS	ABS (HPB)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
			DTG/DIS	DTG	√	-	-	√	-	-
	2007	D4DD (W-ENG)	ABS	ABS (HPB)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
2006	D4DD (W-ENG)	ABS	ABS (HPB)	√	√	√	√	√	-	
		ETACS	ETACS	√	-	-	√	-	-	
2005	D4DD (W-ENG)	ETACS	ETACS	√	-	-	√	-	-	
2004	D4DD (W-ENG)	ETACS	ETACS	√	-	-	√	-	-	
Global900/ GreenCity (KOR)	2011	D6GA (G-ENG)	BCM	BCM	√	√	√	√	√	-
			Engine	C6GA (G-CNG)	-	√	√	√	√	-
		C6GA (G-CNG)	BCM	BCM	√	√	√	√	√	-
			DTG/DIS	DIS	√	√	√	√	-	-
	2010	D6GA (G-ENG)	BCM	BCM	√	√	√	√	√	-
			Engine	C6GA (G-CNG)	-	√	√	√	√	-
		C6GA (G-CNG)	BCM	BCM	√	√	√	√	√	-
	DTG/DIS		DIS	√	√	√	√	-	-	
	2009	D6GA (G-ENG)	ETACS	ETACS	√	-	-	√	-	-
			Engine	C6DA (KK-CNG)	√	√	√	√	√	-
		C6DA (KK-CNG)	ETACS	ETACS	√	-	-	√	-	-
	2008		D6GA (G-ENG)	ETACS	ETACS	√	-	-	√	-
		Engine		C6DA (KK-CNG)	√	√	√	√	√	-
		C6DA (KK-CNG)	ETACS	ETACS	√	-	-	√	-	-
	2007		C6DA (KK-CNG)	Engine	C6DA (KK-CNG)	√	√	√	√	√
		ETACS		ETACS	√	-	-	√	-	-
		DB9A (OM906)	Engine	GLOBAL900 (PLD)	-	√	√	√	√	-
Engine			GLOBAL900 (ADM)	-	√	√	√	√	-	
C6DA (KK-CNG)	ETACS	ETACS	√	-	-	√	-	-		
	Engine	C6DA (KK-CNG)	√	√	√	√	√	-		
ETACS	ETACS	√	-	-	√	-	-			

2006	DB9A (OM906)	Engine	GLOBAL900 (PLD)	-	√	√	√	√	-	
			GLOBAL900 (ADM)	-	√	√	√	√	-	
		ETACS	ETACS	√	-	-	√	-	-	
2005	C6DA (KK-CNG)	Engine	C6DA (KK-CNG)	√	√	√	√	√	-	
		ETACS	ETACS	√	-	-	√	-	-	
	DB9A (OM906)	Engine	GLOBAL900 (PLD)	-	√	√	√	√	-	
		GLOBAL900 (ADM)	-	√	√	√	√	-		
ETACS		ETACS	√	-	-	√	-	-		
2004	C6DA (KK-CNG)	Engine	C6DA (KK-CNG)	√	√	√	√	√	-	
		ETACS	ETACS	√	-	-	√	-	-	
	DB9A (OM906)	Engine	GLOBAL900 (PLD)	-	√	√	√	√	-	
			GLOBAL900 (ADM)	-	√	√	√	√	-	
	ETACS	ETACS	√	-	-	√	-	-		
2003	DB9A (OM906)	Engine	GLOBAL900 (PLD)	-	√	√	√	√	-	
			GLOBAL900 (ADM)	-	√	√	√	√	-	
2002	DB9A (OM906)	Engine	GLOBAL900 (PLD)	-	√	√	√	√	-	
			GLOBAL900 (ADM)	-	√	√	√	√	-	
		ETACS	ETACS	√	-	-	√	-	-	
	D4GA (F-ENG)	DTG/DIS	DTG/DIS	√	√	√	√	-	-	
		D4DD	ETACS	ETACS	√	-	-	√	-	-
		D4BB	ETACS	ETACS	√	-	-	√	-	-
		D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
2011	D4DC	ETACS	ETACS	√	-	-	√	-	-	
		D4DB	ETACS	ETACS	√	-	-	√	-	-
	D4DA	ETACS	ETACS	√	-	-	√	-	-	
	D4GA (F-ENG)	ETACS	ETACS	√	-	-	√	-	-	
		DTG/DIS	DTG/DIS	√	√	√	√	-	-	
		D4DD	ETACS	ETACS	√	-	-	√	-	-
	2010	D4BB	ETACS	ETACS	√	-	-	√	-	-
		D4AF	ETACS	ETACS	√	-	-	√	-	-
D4AL		ETACS	ETACS	√	-	-	√	-	-	
D4DC		ETACS	ETACS	√	-	-	√	-	-	
D4DB		ETACS	ETACS	√	-	-	√	-	-	
D4DA		ETACS	ETACS	√	-	-	√	-	-	
2009		D4DD	ETACS	ETACS	√	-	-	√	-	-
	D4BB	ETACS	ETACS	√	-	-	√	-	-	
	D4AF	ETACS	ETACS	√	-	-	√	-	-	
	D4AL	ETACS	ETACS	√	-	-	√	-	-	

HD35/HD45/ HD65		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
		D4DA	ETACS	ETACS	√	-	-	√	-	-
	2008	D4DD	ETACS	ETACS	√	-	-	√	-	-
		D4BB	ETACS	ETACS	√	-	-	√	-	-
		D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
		D4DA	ETACS	ETACS	√	-	-	√	-	-
	2007	D4DD	ETACS	ETACS	√	-	-	√	-	-
		D4BB	ETACS	ETACS	√	-	-	√	-	-
		D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
		D4DA	ETACS	ETACS	√	-	-	√	-	-
	2006	D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
		D4DA	ETACS	ETACS	√	-	-	√	-	-
	2005	D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
		D4DA	ETACS	ETACS	√	-	-	√	-	-
	2004	D4AF	ETACS	ETACS	√	-	-	√	-	-
D4AL		ETACS	ETACS	√	-	-	√	-	-	
D4DC		ETACS	ETACS	√	-	-	√	-	-	
D4DB		ETACS	ETACS	√	-	-	√	-	-	
D4DA		ETACS	ETACS	√	-	-	√	-	-	
2011	D4GA (F-ENG)	ABS	ABS (MOBIS)						-	
		ABS (HPB)		√	√	√	√	√	-	
		ETACS	ETACS	√	-	-	√	-	-	
	2010	D4GA (F-ENG)	DTG/DIS	DTG	√	-	-	√	-	-
			ABS	ABS (HPB)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
		DTG/DIS	DTG	√	-	-	√	-	-	

e- Mighty (KOR)	2009	D4GA (F-ENG)	ABS	ABS (HPB)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
			DTG/DIS	DTG	√	-	-	√	-	-
	2008	D4GA (F-ENG)	ABS	ABS (HPB)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
			DTG/DIS	DTG	√	-	-	√	-	-
	2007	D4DD (W-ENG)	ABS	ABS (HPB)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
	2006	D4DD (W-ENG)	ABS	ABS (HPB)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
	2005	D4DD (W-ENG)	ABS	ABS (HPB)	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-
	2004	D4DD (W-ENG)	ETACS	ETACS	√	-	-	√	-	-
		2011	D4GA (F-ENG)	ETACS	ETACS	√	-	-	√	-
DTG/DIS				DTG/DIS	√	√	√	√	-	-
D4DD			ETACS	ETACS	√	-	-	√	-	-
D4BB			ETACS	ETACS	√	-	-	√	-	-
D4AF			ETACS	ETACS	√	-	-	√	-	-
D4AL			ETACS	ETACS	√	-	-	√	-	-
D4DC			ETACS	ETACS	√	-	-	√	-	-
D4DB			ETACS	ETACS	√	-	-	√	-	-
D4DA		ETACS	ETACS	√	-	-	√	-	-	
2010		D4GA (F-ENG)	ETACS	ETACS	√	-	-	√	-	-
			DTG/DIS	DTG/DIS	√	√	√	√	-	-
		D4DD	ETACS	ETACS	√	-	-	√	-	-
		D4BB	ETACS	ETACS	√	-	-	√	-	-
		D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
D4DA		ETACS	ETACS	√	-	-	√	-	-	
2009		D4DD	ETACS	ETACS	√	-	-	√	-	-
		D4BB	ETACS	ETACS	√	-	-	√	-	-
		D4AF	ETACS	ETACS	√	-	-	√	-	-
		D4AL	ETACS	ETACS	√	-	-	√	-	-
		D4DC	ETACS	ETACS	√	-	-	√	-	-
		D4DB	ETACS	ETACS	√	-	-	√	-	-
		D4DA	ETACS	ETACS	√	-	-	√	-	-
D4DD		ETACS	ETACS	√	-	-	√	-	-	

HD72/HD75/
HD78

2008	D4BB	ETACS	ETACS	✓	-	-	✓	-	-	
	D4AF	ETACS	ETACS	✓	-	-	✓	-	-	
	D4AL	ETACS	ETACS	✓	-	-	✓	-	-	
	D4DC	ETACS	ETACS	✓	-	-	✓	-	-	
	D4DB	ETACS	ETACS	✓	-	-	✓	-	-	
	D4DA	ETACS	ETACS	✓	-	-	✓	-	-	
	2007	D4DD	ETACS	ETACS	✓	-	-	✓	-	-
		D4BB	ETACS	ETACS	✓	-	-	✓	-	-
		D4AF	ETACS	ETACS	✓	-	-	✓	-	-
		D4AL	ETACS	ETACS	✓	-	-	✓	-	-
		D4DC	ETACS	ETACS	✓	-	-	✓	-	-
		D4DB	ETACS	ETACS	✓	-	-	✓	-	-
		D4DA	ETACS	ETACS	✓	-	-	✓	-	-
	2006	D4AF	ETACS	ETACS	✓	-	-	✓	-	-
		D4AL	ETACS	ETACS	✓	-	-	✓	-	-
		D4DC	ETACS	ETACS	✓	-	-	✓	-	-
		D4DB	ETACS	ETACS	✓	-	-	✓	-	-
		D4DA	ETACS	ETACS	✓	-	-	✓	-	-
	2005	D4AF	ETACS	ETACS	✓	-	-	✓	-	-
		D4AL	ETACS	ETACS	✓	-	-	✓	-	-
		D4DC	ETACS	ETACS	✓	-	-	✓	-	-
D4DB		ETACS	ETACS	✓	-	-	✓	-	-	
D4DA		ETACS	ETACS	✓	-	-	✓	-	-	
2004	D4AF	ETACS	ETACS	✓	-	-	✓	-	-	
	D4AL	ETACS	ETACS	✓	-	-	✓	-	-	
	D4DC	ETACS	ETACS	✓	-	-	✓	-	-	
	D4DB	ETACS	ETACS	✓	-	-	✓	-	-	
	D4DA	ETACS	ETACS	✓	-	-	✓	-	-	
2011	D6GA (G-ENG)	BCM	BCM	✓	✓	✓	✓	✓	-	
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
			DTG	✓	-	-	✓	-	-	
			DIS	✓	✓	✓	✓	-	-	
	C6GA (G-CNG)	Engine	C6GA (G-CNG)	-	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
		DTG/DIS	DIS	✓	✓	✓	✓	-	-	
	C6DA (KK-CNG)	Engine	C6DA (KK-CNG)	✓	✓	✓	✓	✓	-	
BCM		BCM	✓	✓	✓	✓	✓	-		
D6GA (G-ENG)	BCM	BCM	✓	✓	✓	✓	✓	-		
		DTG/DIS	✓	✓	✓	✓	-	-		

Hyundai

Mega Truck (KOR)	2010	D6GA (G-ENG)	DTG/DIS	DTG	✓	-	-	✓	-	-	
				DIS	✓	✓	✓	✓	-	-	
		C6GA (G-CNG)	Engine	C6GA (G-CNG)	-	✓	✓	✓	✓	✓	-
			BCM	BCM	✓	✓	✓	✓	✓	✓	-
			DTG/DIS	DIS	✓	✓	✓	✓	✓	-	-
		C6DA (KK-CNG)	Engine	C6DA (KK-CNG)	✓	✓	✓	✓	✓	✓	-
	BCM		BCM	✓	✓	✓	✓	✓	✓	-	
	2009	D6GA (G-ENG)	ETACS	ETACS	✓	-	-	✓	-	-	
			DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
				DTG	✓	-	-	✓	-	-	
		C6DA (KK-CNG)	Engine	C6DA (KK-CNG)	✓	✓	✓	✓	✓	-	
	ETACS		ETACS	✓	-	-	✓	-	-		
	2008	D6GA (G-ENG)	ETACS	ETACS	✓	-	-	✓	-	-	
			DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
				DTG	✓	-	-	✓	-	-	
		C6DA (KK-CNG)	Engine	C6DA (KK-CNG)	✓	✓	✓	✓	✓	-	
	ETACS		ETACS	✓	-	-	✓	-	-		
	2007	D6DB (K-ENG)	Engine	D6DB (K-ENG)	✓	✓	✓	✓	✓	-	
			ETACS	ETACS	✓	-	-	✓	-	-	
		C6DA (KK-CNG)	Engine	C6DA (KK-CNG)	✓	✓	✓	✓	✓	-	
			ETACS	ETACS	✓	-	-	✓	-	-	
	2006	D6DB (K-ENG)	Engine	D6DB (K-ENG)	✓	✓	✓	✓	✓	-	
			ETACS	ETACS	✓	-	-	✓	-	-	
		C6DA (KK-CNG)	Engine	C6DA (KK-CNG)	✓	✓	✓	✓	✓	-	
			ETACS	ETACS	✓	-	-	✓	-	-	
	2005	D6DB (K-ENG)	Engine	D6DB (K-ENG)	✓	✓	✓	✓	✓	-	
			ETACS	ETACS	✓	-	-	✓	-	-	
C6DA (KK-CNG)		Engine	C6DA (KK-CNG)	✓	✓	✓	✓	✓	-		
		ETACS	ETACS	✓	-	-	✓	-	-		
2011	D6CC (L-ENG)	Engine	D6CC (L-ENG)	✓	✓	✓	✓	✓	-		
		ETACS	ETACS	✓	-	-	✓	-	-		
	D6CB (L-ENG)	Engine	D6CB	✓	✓	✓	✓	✓	-		
			D6CB (Euro 4 Injection)	✓	✓	✓	✓	✓	-		
		ETACS	ETACS	✓	-	-	✓	-	-		
	D6CA (L-ENG)	Engine	D6CA	✓	✓	✓	✓	✓	-		
			D6CA (Euro 4 Injection)	✓	✓	✓	✓	✓	-		
		ETACS	ETACS	✓	-	-	✓	-	-		
D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-			
	ETACS	ETACS	✓	-	-	✓	-	-			

Heavy Duty
Truck

2010	D6CC (L-ENG)	Engine	D6CC (L-ENG)	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
	D6CB	Engine	D6CB	✓	✓	✓	✓	✓	-	
			D6CB (Euro 4 Injection)	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
			D6CA (Euro 4 Injection)	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
	2009	D6CB	Engine	D6CB	✓	✓	✓	✓	✓	-
				D6CB (Euro 4 Injection)	✓	✓	✓	✓	✓	-
			ETACS	ETACS	✓	-	-	✓	-	-
		D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-
D6CA (Euro 4 Injection)				✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-		
	ETACS	ETACS	✓	-	-	✓	-	-		
2008	D6CB	Engine	D6CB	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-		
	ETACS	ETACS	✓	-	-	✓	-	-		
2007	D6CB	Engine	D6CB	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-		
	ETACS	ETACS	✓	-	-	✓	-	-		
2006	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
2005	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
		ETACS	ETACS	✓	-	-	✓	-	-	
	Engine	D6CA	✓	✓	✓	✓	✓	-		

2004	D6CA	ETACS	ETACS	√	-	-	√	-	-
	D6AB	Engine	D6AB	√	√	√	√	√	-
2003		D6CA	ETACS	ETACS	√	-	-	√	-
	Engine		D6CA	√	√	√	√	√	-
	D6AB	Engine	D6AB	√	√	√	√	√	-
		ETACS	ETACS	√	-	-	√	-	-
2011	D6HA (H-ENG)	Engine	D6HA (H-ENG)	√	√	√	√	√	-
			D6HA (H-ENG 10EM)	√	√	√	√	√	-
		AT	Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-
		ABS	ABS/EBS (WABCO)	√	√	√	√	√	-
		INHIBITOR	RANGE INHIBITOR	-	-	-	√	√	-
		BCM	BCM	√	√	√	√	√	-
	DTG/DIS	DTG/DIS	√	√	√	√	-	-	
		DTG	√	-	-	√	-	-	
		DIS	√	√	√	√	-	-	
	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	√	√	√	√	√	-
		BCM	BCM	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG	√	-	-	√	-	-
	C6AE (Q-CNG)	Engine	C6AE (Q-CNG)	√	√	√	√	√	-
		BCM	BCM	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DIS	√	√	√	√	-	-
	2010	D6HA (H-ENG)	Engine	D6HA (H-ENG)	√	√	√	√	√
D6HA (H-ENG 10EM)				√	√	√	√	√	-
AT			Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-
ABS			ABS/EBS (WABCO)	√	√	√	√	√	-
INHIBITOR			RANGE INHIBITOR	-	-	-	√	√	-
BCM			BCM	√	√	√	√	√	-
DTG/DIS		DTG/DIS	√	√	√	√	-	-	
		DTG	√	-	-	√	-	-	
		DIS	√	√	√	√	-	-	
C6AC (Q-CNG)		Engine	C6AC (Q-CNG)	√	√	√	√	√	-
		BCM	BCM	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
	DTG		√	-	-	√	-	-	
	Engine	C6AE (Q-CNG)	√	√	√	√	√	-	

New Power Truck (KOR)

2009	C6AE (Q-CNG)	BCM	BCM	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG	√	-	-	√	-	-
			DIS	√	√	√	√	-	-
	D6HA (H-ENG)	Engine	D6HA (H-ENG)	√	√	√	√	√	-
		AT	Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-
		ABS/EBS	ABS/EBS (WABCO)	√	√	√	√	√	-
		INHIBITOR	RANGE INHIBITOR	-	-	-	√	√	-
		BCM	BCM	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
	DTG		√	-	-	√	-	-	
	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	√	√	√	√	√	-
ETACS		ETACS	√	-	-	√	-	-	
DTG/DIS		DTG/DIS	√	√	√	√	-	-	
		DTG	√	-	-	√	-	-	
2008	D6HA (H-ENG)	Engine	D6HA (H-ENG)	√	√	√	√	√	-
		AT	Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-
		ABS/EBS	ABS/EBS (WABCO)	√	√	√	√	√	-
		INHIBITOR	RANGE INHIBITOR	-	-	-	√	√	-
		BCM	BCM	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
	DTG		√	-	-	√	-	-	
	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	√	√	√	√	√	-
		ETACS	ETACS	√	-	-	√	-	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG	√	-	-	√	-	-
	2007	D6CB (L-ENG)	Engine	D6CB (L-ENG)	√	√	√	√	√
BCM			BCM	√	√	√	√	√	-
C6AC (Q-CNG)		Engine	C6AC (Q-CNG)	√	√	√	√	√	-
		ETACS	ETACS	√	-	-	√	-	-
D6AB (Q-DD ENG)		Engine	D6AB (Q-DD ENG)	√	√	√	√	√	-
		BCM	BCM	√	√	√	√	√	-
2006	D6CB (L-ENG)	Engine	D6CB (L-ENG)	√	√	√	√	√	-
		ETACS	ETACS	√	-	-	√	-	-
	C6AB (Q-CNG)	ETACS	ETACS	√	-	-	√	-	-
		Engine	D6AB (Q-DD ENG)	√	√	√	√	√	-
	D6AB (Q-DD ENG)	ETACS	ETACS	√	-	-	√	-	-
		Engine	D6CB (L-ENG)	√	√	√	√	√	-
D6CB (L-ENG)	ETACS	ETACS	√	-	-	√	-	-	

2005	C6AB(Q-CNG)	ETACS	ETACS	√	-	-	√	-	-
	D6AB(Q-DD ENG)	Engine	D6AB(Q-DD ENG)	√	√	√	√	√	-
2004	D6CB(L-ENG)	ETACS	ETACS	√	-	-	√	-	-
		Engine	D6CB(L-ENG)	√	√	√	√	√	-
	D6CA(L-ENG)	ETACS	ETACS	√	-	-	√	-	-
		Engine	D6CA(L-ENG)	√	√	√	√	√	-
	C6AB(Q-CNG)	ETACS	ETACS	√	-	-	√	-	-
	D6AB(Q-DD ENG)	Engine	D6AB(Q-DD ENG)	√	√	√	√	√	-
		ETACS	ETACS	√	-	-	√	-	-
2003	D6CA(L-ENG)	Engine	D6CA(L-ENG)	√	√	√	√	√	-
	D6AB(Q-DD ENG)	Engine	D6AB(Q-DD ENG)	√	√	√	√	√	-
2002	D6CA(L-ENG)	Engine	D6CA(L-ENG)	√	√	√	√	√	-
	D6AB(Q-DD ENG)	Engine	D6AB(Q-DD ENG)	√	√	√	√	√	-
2001	D6CA(L-ENG)	Engine	D6CA(L-ENG)	√	√	√	√	√	-
	D6AB(Q-DD ENG)	Engine	D6AB(Q-DD ENG)	√	√	√	√	√	-
2000	D6CA(L-ENG)	Engine	D6CA(L-ENG)	√	√	√	√	√	-
	D6AB(Q-DD ENG)	Engine	D6AB(Q-DD ENG)	√	√	√	√	√	-
		ABS	ABS(WABCO)						-
2000	D6HA(H-ENG)	Engine	D6HA(H-ENG)	√	√	√	√	√	-
			D6HA(H-ENG 10EM)	√	√	√	√	√	-
		AT	Astronic ATM2(ZF16AS230)	√	√	√	√	√	-
		ABS/EBS	ABS/EBS(WABCO)	√	√	√	√	√	-
		INTARDER	ZF Intarder	√	√	√	√	√	-
		ECAS	ECAS(WABCO)	√	√	√	√	√	-
		INHIBITOR	RANGE INHIBITOR	-	-	-	√	√	-
		BCM	BCM	√	√	√	√	√	-
		LDWS	LDWS	√	√	√	√	√	-
			DTG/DIS	DTG/DIS	√	√	√	√	-
	DTG			√	-	-	√	-	
	DIS	√	√	√	√	-			
	D6CC(L-ENG)	Engine	D6CC(L-ENG)	√	√	√	√	√	-
		AT	Astronic ATM2(ZF16AS230)	√	√	√	√	√	-
		ABS/EBS	ABS/EBS(WABCO)	√	√	√	√	√	-
INTARDER		ZF Intarder	√	√	√	√	√	-	
ECAS		ECAS(WABCO)	√	√	√	√	√	-	
INHIBITOR		RANGE INHIBITOR	-	-	-	√	√	-	
BCM		BCM	√	√	√	√	√	-	
LDWS	LDWS	√	√	√	√	√	-		

2011	D6CD (L-ENG)	DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG	√	-	-	√	-	-
		Engine	D6CD (L-ENG)	√	√	√	√	√	-
		AT	Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-
		ABS/EBS	ABS/EBS (WABCO)	√	√	√	√	√	-
		INTARDER	ZF Intarder	√	√	√	√	√	-
		ECAS	ECAS (WABCO)	√	√	√	√	√	-
		INHIBITOR	RANGE INHIBITOR	-	-	-	√	√	-
		BCM	BCM	√	√	√	√	√	-
		LDWS	LDWS	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG	√	-	-	√	-	-
	DIS		√	√	√	√	-	-	
	D6CE (L-ENG)	Engine	D6CE (L-ENG)	√	√	√	√	√	-
		AT	Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-
		ABS/EBS	ABS/EBS (WABCO)	√	√	√	√	√	-
		INTARDER	ZF Intarder	√	√	√	√	√	-
		ECAS	ECAS (WABCO)	√	√	√	√	√	-
		INHIBITOR	RANGE INHIBITOR	-	-	-	√	√	-
		BCM	BCM	√	√	√	√	√	-
		LDWS	LDWS	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG	√	-	-	√	-	-
			DIS	√	√	√	√	-	-
		D6HA (H-ENG)	Engine	D6HA (H-ENG)	√	√	√	√	√
	D6HA (H-ENG 10EM)			√	√	√	√	√	-
	AT		Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-
	ABS/EBS		ABS/EBS (WABCO)	√	√	√	√	√	-
	INTARDER		ZF Intarder	√	√	√	√	√	-
	ECAS		ECAS (WABCO)	√	√	√	√	√	-
INHIBITOR	RANGE INHIBITOR		-	-	-	√	√	-	
BCM	BCM		√	√	√	√	√	-	
LDWS	LDWS		√	√	√	√	√	-	
DTG/DIS	DTG/DIS		√	√	√	√	-	-	
	DTG		√	-	-	√	-	-	
	DIS		√	√	√	√	-	-	
D6CC (L-ENG)	Engine	D6CC (L-ENG)	√	√	√	√	√	-	
	AT	Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-	
	ABS/EBS	ABS/EBS (WABCO)	√	√	√	√	√	-	

Trago (KOR)

2010

D6CC (L-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-		
	ECAS	ECAS (WABCO)	√	√	√	√	√	-		
	INHIBITOR	RANGE INHIBITOR	-	-	-	√	√	-		
	BCM	BCM	√	√	√	√	√	-		
	LDWS	LDWS	√	√	√	√	√	-		
	DTG/DIS	DTG/DIS		√	√	√	√	-	-	
		DTG		√	-	-	√	-	-	
	D6CD (L-ENG)	Engine	D6CD (L-ENG)	√	√	√	√	√	-	
		AT	Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-	
		ABS/EBS	ABS/EBS (WABCO)	√	√	√	√	√	-	
		INTARDER	ZF Intarder	√	√	√	√	√	-	
		ECAS	ECAS (WABCO)	√	√	√	√	√	-	
		INHIBITOR	RANGE INHIBITOR	-	-	-	√	√	-	
		BCM	BCM	√	√	√	√	√	-	
		LDWS	LDWS	√	√	√	√	√	-	
		DTG/DIS	DTG/DIS		√	√	√	√	-	-
			DTG		√	-	-	√	-	-
	DIS			√	√	√	√	-	-	
	D6CE (L-ENG)	Engine	D6CE (L-ENG)	√	√	√	√	√	-	
		AT	Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-	
		ABS/EBS	ABS/EBS (WABCO)	√	√	√	√	√	-	
INTARDER		ZF Intarder	√	√	√	√	√	-		
ECAS		ECAS (WABCO)	√	√	√	√	√	-		
INHIBITOR		RANGE INHIBITOR	-	-	-	√	√	-		
BCM		BCM	√	√	√	√	√	-		
LDWS		LDWS	√	√	√	√	√	-		
DTG/DIS		DTG/DIS		√	√	√	√	-	-	
		DTG		√	-	-	√	-	-	
	DIS		√	√	√	√	-	-		
D6HA (H-ENG)	Engine	D6HA (H-ENG)	√	√	√	√	√	-		
	AT	Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-		
	AT	ABS/EBS (WABCO)	√	√	√	√	√	-		
	INTARDER	ZF Intarder	√	√	√	√	√	-		
	ECAS	ECAS (WABCO)	√	√	√	√	√	-		
	INHIBITOR	RANGE INHIBITOR	-	-	-	√	√	-		
	BCM	BCM	√	√	√	√	√	-		
	LDWS	LDWS	√	√	√	√	√	-		
	DTG/DIS	DTG/DIS		√	√	√	√	-	-	
DTG			√	-	-	√	-	-		

2000

2009	D6CC (L-ENG)	Engine	D6CC (L-ENG)	√	√	√	√	√	-
		AT	Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-
		ABS/EBS	ABS/EBS (WABCO)	√	√	√	√	√	-
		INTARDER	ZF Intarder	√	√	√	√	√	-
		ECAS	ECAS (WABCO)	√	√	√	√	√	-
		INHIBITOR	RANGE INHIBITOR	-	-	-	√	√	-
		BCM	BCM	√	√	√	√	√	-
		LDWS	LDWS	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG	√	-	-	√	-	-
2008	D6HA (H-ENG)	Engine	D6HA (H-ENG)	√	√	√	√	√	-
		AT	Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-
		ABS/EBS	ABS/EBS (WABCO)	√	√	√	√	√	-
		INTARDER	ZF Intarder	√	√	√	√	√	-
		ECAS	ECAS (WABCO)	√	√	√	√	√	-
		INHIBITOR	RANGE INHIBITOR	-	-	-	√	√	-
		BCM	BCM	√	√	√	√	√	-
		LDWS	LDWS	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG	√	-	-	√	-	-
2008	D6CC (L-ENG)	Engine	D6CC (L-ENG)	√	√	√	√	√	-
		AT	Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-
		ABS/EBS	ABS/EBS (WABCO)	√	√	√	√	√	-
		INTARDER	ZF Intarder	√	√	√	√	√	-
		ECAS	ECAS (WABCO)	√	√	√	√	√	-
		INHIBITOR	RANGE INHIBITOR	-	-	-	√	√	-
		BCM	BCM	√	√	√	√	√	-
		LDWS	LDWS	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG	√	-	-	√	-	-
2008	D6CB (L-ENG)	Engine	D6CB (L-ENG)	√	√	√	√	√	-
		AT	Astronic ATM2 (ZF16AS23)	√	√	√	√	√	-
		ABS/EBS	ABS/EBS (WABCO)	√	√	√	√	√	-
		INTARDER	ZF Intarder	√	√	√	√	√	-
		ECAS	ECAS (WABCO)	√	√	√	√	√	-
		ETACS	ETACS	√	-	-	√	-	-
		LDWS	LDWS	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
DTG	√		-	-	√	-	-		

2007	D6CB(L-ENG)	Engine	D6CB(L-ENG)	√	√	√	√	√	-
		AT	Astronic ATM2(ZF16AS23)	√	√	√	√	√	-
		ABS/EBS	ABS/EBS(WABCO)	√	√	√	√	√	-
		INTARDER	ZF Intarder	√	√	√	√	√	-
		ECAS	ECAS(WABCO)	√	√	√	√	√	-
		ETACS	ETACS	√	-	-	√	-	-
		LDWS	LDWS	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
DTG	√		-	-	√	-	-		
2011	D6CC(L-ENG)	Engine	D6CC(L-ENG)	√	√	√	√	√	-
		INTARDER	ZF Intarder	√	√	√	√	√	-
		BCM	BCM	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG	√	-	-	√	-	-
	D6CB(L-ENG)	Engine	D6CB(L-ENG)	√	√	√	√	√	-
			D6CB(Euro 4 Injection)	√	√	√	√	√	-
		INTARDER	ZF Intarder	√	√	√	√	√	-
		BCM	BCM	√	√	√	√	√	-
	DTG/DIS	DTG/DIS	√	√	√	√	-	-	
	D6CA(L-ENG)	Engine	D6CA(L-ENG)	√	√	√	√	√	-
			D6CA(Eruo 4 Injection)	√	√	√	√	√	-
		BCM	BCM	√	√	√	√	√	-
	D6AB	Engine	D6AB	√	√	√	√	√	-
		BCM	BCM	√	√	√	√	√	-
	D6AC	BCM	BCM	√	√	√	√	√	-
	D6AV	BCM	BCM	√	√	√	√	√	-
	D6HA(H-ENG)	Engine	D6HA(H-ENG)	√	√	√	√	√	-
		INTARDER	ZF Intarder	√	√	√	√	√	-
		BCM	BCM	√	√	√	√	√	-
		ADR	ADR	√	√	√	√	√	-
		LDWS	LDWS	√	√	√	√	√	-
		DTG/DIS	DTG/DIS	√	√	√	√	-	-
			DTG	√	-	-	√	-	-
	D6CC(L-ENG)	Engine	D6CC(L-ENG)	√	√	√	√	√	-
			D6CC(L-ENG JAPAN)	√	√	√	√	√	-
		INTARDER	ZF Intarder	√	√	√	√	√	-
		BCM	BCM	√	√	√	√	√	-
DTG/DIS		DTG/DIS	√	√	√	√	-	-	
		DTG	√	-	-	√	-	-	

Universe

2010	D6CB	Engine	D6CB	✓	✓	✓	✓	✓	-	
			D6CB(Euro 4 Injection)	✓	✓	✓	✓	✓	-	
		INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
			D6CA(Eruo 4 Injection)	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
	D6AC	BCM	BCM	✓	✓	✓	✓	✓	-	
	D6AV	BCM	BCM	✓	✓	✓	✓	✓	-	
	2009	D6CC(L-ENG)	Engine	D6CC(L-ENG JAPAN)	✓	✓	✓	✓	✓	-
			INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-
BCM			BCM	✓	✓	✓	✓	✓	-	
DTG/DIS			DTG/DIS	✓	✓	✓	✓	-	-	
			DTG	✓	-	-	✓	-	-	
D6CB		Engine	D6CB	✓	✓	✓	✓	✓	-	
			D6CB(Euro 4 Injection)	✓	✓	✓	✓	✓	-	
		INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
D6CA		Engine	D6CA	✓	✓	✓	✓	✓	-	
			D6CA(Eruo 4 Injection)	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
D6AB		Engine	D6AB	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
D6AC		BCM	BCM	✓	✓	✓	✓	✓	-	
D6AV		BCM	BCM	✓	✓	✓	✓	✓	-	
2008		D6CB	Engine	D6CB	✓	✓	✓	✓	✓	-
	INTARDER		ZF Intarder	✓	✓	✓	✓	✓	-	
	BCM		BCM	✓	✓	✓	✓	✓	-	
	DTG/DIS		DTG/DIS	✓	✓	✓	✓	-	-	
	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
	D6AC	BCM	BCM	✓	✓	✓	✓	✓	-	
	D6AV	BCM	BCM	✓	✓	✓	✓	✓	-	

2007	D6CB	Engine	D6CB	✓	✓	✓	✓	✓	-	
		INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
	D6CA	Engine	D6CA	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
	D6AB	Engine	D6AB	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
	D6AC	BCM	BCM	✓	✓	✓	✓	✓	-	
	D6AV	BCM	BCM	✓	✓	✓	✓	✓	-	
	2011	D6HA (H-ENG)	Engine	D6HA (H-ENG)	✓	✓	✓	✓	✓	-
				D6HA (H-ENG 10EM)	✓	✓	✓	✓	✓	-
			INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-
			BCM	BCM	✓	✓	✓	✓	✓	-
ADR			ADR	✓	✓	✓	✓	✓	-	
LDWS			LDWS	✓	✓	✓	✓	✓	-	
DTG/DIS			DTG/DIS	✓	✓	✓	✓	-	-	
			DTG	✓	-	-	✓	-	-	
		DIS	✓	✓	✓	✓	-	-		
D6CC (L-ENG)		Engine	D6CC (L-ENG)	✓	✓	✓	✓	✓	-	
		INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
		ADR	ADR	✓	✓	✓	✓	✓	-	
		LDWS	LDWS	✓	✓	✓	✓	✓	-	
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
DTG			✓	-	-	✓	-	-		
D6CD (L-ENG)		Engine	D6CD (L-ENG)	✓	✓	✓	✓	✓	-	
		INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
		ADR	ADR	✓	✓	✓	✓	✓	-	
		LDWS	LDWS	✓	✓	✓	✓	✓	-	
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
DTG			✓	-	-	✓	-	-		
DIS			✓	✓	✓	✓	-	-		
C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-		
	INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-		
	BCM	BCM	✓	✓	✓	✓	✓	-		
	ADR	ADR	✓	✓	✓	✓	✓	-		
	LDWS	LDWS	✓	✓	✓	✓	✓	-		

Universe (KOR)	2010	C6AE (Q-CNG)	DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
				DTG	✓	-	-	✓	-	-	
			Engine	C6AE (Q-CNG)	✓	✓	✓	✓	✓	-	-
				BCM	✓	✓	✓	✓	✓	-	-
			ADR	✓	✓	✓	✓	✓	-	-	
			LDWS	✓	✓	✓	✓	✓	-	-	
			DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
				DTG	✓	-	-	✓	-	-	
				DIS	✓	✓	✓	✓	-	-	
			D6HA (H-ENG)	Engine	D6HA (H-ENG)	✓	✓	✓	✓	✓	-
	D6HA (H-ENG 10EM)	✓			✓	✓	✓	✓	-		
	INTARDER	ZF Intarder		✓	✓	✓	✓	✓	-		
	BCM	BCM		✓	✓	✓	✓	✓	-		
	ADR	ADR		✓	✓	✓	✓	✓	-		
	LDWS	LDWS		✓	✓	✓	✓	✓	-		
	DTG/DIS	DTG/DIS		✓	✓	✓	✓	-	-		
		DTG	✓	-	-	✓	-	-			
		DIS	✓	✓	✓	✓	-	-			
	D6CC (L-ENG)	Engine	D6CC (L-ENG)	✓	✓	✓	✓	✓	-		
			INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-		
		ADR	ADR	✓	✓	✓	✓	✓	-		
		LDWS	LDWS	✓	✓	✓	✓	✓	-		
		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-		
	DTG		✓	-	-	✓	-	-			
	D6CD (L-ENG)	Engine	D6CD (L-ENG)	✓	✓	✓	✓	✓	-		
			INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-		
ADR		ADR	✓	✓	✓	✓	✓	-			
LDWS		LDWS	✓	✓	✓	✓	✓	-			
DTG/DIS		DTG/DIS	✓	✓	✓	✓	-	-			
	DTG	✓	-	-	✓	-	-				
	DIS	✓	✓	✓	✓	-	-				
C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-			
		INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-		
	BCM	BCM	✓	✓	✓	✓	✓	-			
	ADR	ADR	✓	✓	✓	✓	✓	-			
	LDWS	LDWS	✓	✓	✓	✓	✓	-			
	DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-			

2009	C6AE (Q-CNG)	DTG/DIS	DTG	✓	-	-	✓	-	-	
		Engine	C6AE (Q-CNG)	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
		ADR	ADR	✓	✓	✓	✓	✓	-	
		LDWS	LDWS	✓	✓	✓	✓	✓	-	
		DTG/DIS	DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
			DTG	DTG	✓	-	-	✓	-	-
DIS	DIS		✓	✓	✓	✓	-	-		
2009	D6HA (H-ENG)	Engine	D6HA (H-ENG)	✓	✓	✓	✓	✓	-	
		INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
		ADR	ADR	✓	✓	✓	✓	✓	-	
		LDWS	LDWS	✓	✓	✓	✓	✓	-	
		DTG/DIS	DTG	✓	-	-	✓	-	-	
	D6CC (L-ENG)	Engine	D6CC (L-ENG)	✓	✓	✓	✓	✓	-	
		INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
		ADR	ADR	✓	✓	✓	✓	✓	-	
		LDWS	LDWS	✓	✓	✓	✓	✓	-	
		DTG/DIS	DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
	DTG		DTG	✓	-	-	✓	-	-	
	C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	✓	✓	✓	✓	✓	-	
INTARDER		ZF Intarder	✓	✓	✓	✓	✓	-		
BCM		BCM	✓	✓	✓	✓	✓	-		
ADR		ADR	✓	✓	✓	✓	✓	-		
LDWS		LDWS	✓	✓	✓	✓	✓	-		
DTG/DIS		DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-	
	DTG	DTG	✓	-	-	✓	-	-		
2009	D6HA (H-ENG)	Engine	D6HA (H-ENG)	✓	✓	✓	✓	✓	-	
		INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
		ADR	ADR	✓	✓	✓	✓	✓	-	
		LDWS	LDWS	✓	✓	✓	✓	✓	-	
		DTG/DIS	DTG/DIS	DTG/DIS	✓	✓	✓	✓	-	-
	DTG		DTG	✓	-	-	✓	-	-	
	D6CC (L-ENG)	Engine	D6CC (L-ENG)	✓	✓	✓	✓	✓	-	
		INTARDER	ZF Intarder	✓	✓	✓	✓	✓	-	
		BCM	BCM	✓	✓	✓	✓	✓	-	
ADR		ADR	✓	✓	✓	✓	✓	-		

New Granbird	2008		LDWS	LDWS	√	√	√	√	√	-	
			DTG/DIS	DTG/DIS	√	√	√	√	-	-	
		D6CB (L-ENG)	Engine	D6CB (L-ENG)	√	√	√	√	√	√	-
			INTARDER	ZF Intarder	√	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-	-
			ADR	ADR	√	√	√	√	√	√	-
			LDWS	LDWS	√	√	√	√	√	√	-
			DTG/DIS	DTG/DIS	√	√	√	√	√	-	-
		C6AC (Q-CNG)	Engine	C6AC (Q-CNG)	√	√	√	√	√	√	-
			INTARDER	ZF Intarder	√	√	√	√	√	√	-
			BCM	BCM	√	√	√	√	√	√	-
			ADR	ADR	√	√	√	√	√	√	-
	LDWS		LDWS	√	√	√	√	√	√	-	
	DTG/DIS		DTG/DIS	√	√	√	√	√	-	-	
	2007	D6CB (L-ENG)	DTG	DTG	√	-	-	√	-	-	-
			Engine	D6CB (L-ENG)	√	√	√	√	√	√	-
			INTARDER	ZF Intarder	√	√	√	√	√	√	-
			ETACS	ETACS	√	-	-	√	-	-	-
			ADR	ADR	√	√	√	√	√	√	-
			LDWS	LDWS	√	√	√	√	√	√	-
2011	D6CC (L-ENG)	DTG/DIS	DTG/DIS	√	√	√	√	√	-	-	
		Engine	D6CC (L-ENG)	√	√	√	√	√	√	-	
		INTARDER	ZF Intarder	√	√	√	√	√	√	-	
		BCM	BCM	√	√	√	√	√	√	-	
	D6HA (H-ENG)	DTG	DTG	√	-	-	√	-	-	-	
		Engine	D6HA (H-ENG)	√	√	√	√	√	√	-	
		INTARDER	ZF Intarder	√	√	√	√	√	√	-	
		BCM	BCM	√	√	√	√	√	√	-	
	2010	D6CC (L-ENG)	DTG/DIS	DTG	√	-	-	√	-	-	-
			Engine	D6CC (L-ENG)	√	√	√	√	√	√	-
			INTARDER	ZF Intarder	√	√	√	√	√	√	-
			BCM	BCM	√	√	√	√	√	√	-
D6HA (H-ENG)		DTG/DIS	DTG	√	-	-	√	-	-	-	
		Engine	D6HA (H-ENG)	√	√	√	√	√	√	-	
		INTARDER	ZF Intarder	√	√	√	√	√	√	-	
		BCM	BCM	√	√	√	√	√	√	-	
	D6CC (L-ENG)	DTG/DIS	DTG	√	-	-	√	-	-	-	
		Engine	D6CC (L-ENG)	√	√	√	√	√	√	-	
	D6HA (H-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	√	-	
		BCM	BCM	√	√	√	√	√	√	-	

	2009	D6CC (L-ENG)	BCM	BCM	√	√	√	√	√	-		
			DTG/DIS	DTG	√	-	-	√	-	-		
		D6HA (H-ENG)	Engine	D6HA (H-ENG)	√	√	√	√	√	√	-	
			INTARDER	ZF Intarder	√	√	√	√	√	√	-	
			BCM	BCM	√	√	√	√	√	√	-	
			DTG/DIS	DTG	√	-	-	√	-	-		
		2008	D6CC (L-ENG)	Engine	D6CC (L-ENG)	√	√	√	√	√	√	-
				INTARDER	ZF Intarder	√	√	√	√	√	√	-
	BCM			BCM	√	√	√	√	√	√	-	
	DTG/DIS			DTG	√	-	-	√	-	-		
	D6HA (H-ENG)		Engine	D6HA (H-ENG)	√	√	√	√	√	√	-	
			INTARDER	ZF Intarder	√	√	√	√	√	√	-	
			BCM	BCM	√	√	√	√	√	√	-	
			DTG/DIS	DTG	√	-	-	√	-	-		
	Granbird	2007	D6CB (L-ENG)	Engine	D6CB (L-ENG)	√	√	√	√	√	-	
		2006	D6CB (L-ENG)	Engine	D6CB (L-ENG)	√	√	√	√	√	-	
2005		D6CB (L-ENG)	Engine	D6CB (L-ENG)	√	√	√	√	√	-		
2004		D6CA (L-ENG)	Engine	D6CA (L-ENG)	√	√	√	√	√	-		
		D6CB (L-ENG)	Engine	D6CB (L-ENG)	√	√	√	√	√	-		
2003		D6CA (L-ENG)	Engine	D6CA (L-ENG)	√	√	√	√	√	-		
		D6AB (Q-ENG)	Engine	D6AB (Q-ENG)	√	√	√	√	√	-		
2002		D6CA (L-ENG)	Engine	D6CA (L-ENG)	√	√	√	√	√	-		
		D6AB (Q-ENG)	Engine	D6AB (Q-ENG)	√	√	√	√	√	-		
2001		D6CA (L-ENG)	Engine	D6CA (L-ENG)	√	√	√	√	√	-		
	D6AB (Q-ENG)	Engine	D6AB (Q-ENG)	√	√	√	√	√	-			
KM928	2004	D6AB (Q-ENG)	Engine	D6AB (Q-ENG)	√	√	√	√	√	-		
	2003	D6AB (Q-ENG)	Engine	D6AB (Q-ENG)	√	√	√	√	√	-		
	2001	D6AB (Q-ENG)	Engine	D6AB (Q-ENG)	√	√	√	√	√	-		

Remark: √ means the system has the function -means not