



**FCAR F3 Diagnostic List** (Note:For reference only)

Automaker:

Benz

Version:

V8.9

Model	Model Year	Class	Chassis	ECU	System	Function						
						Version info.	Read DTC	Clear DTC	Read Data Stream	Actuation test	Special function	Other
Benz	-	S	140	Gasoline Engine	HFM-Hot film engine control	√	√	√	√	-	-	-
					ME2-engine ECU	√	√	√	√	√	-	-
					ME1RE-Engine	√	√	√	√	√	-	-
					ME1LI-Engine	√	-	-	√	√	-	-
					LH1SFI-Engine	√	√	√	√	-	-	-
					LH2SFI-Engine	√	√	√	√	-	-	-
					DM-diagnostic module	√	√	√	√	-	-	√
					GM-general module(basic computer BM)	√	√	√	√	-	-	-
					EFP-Electronic Throttle(EA,CC,ISC)	√	√	√	√	√	-	-
					EZ1-Electronic Ignition	√	√	√	√	-	-	-
					EZ2-Electronic Ignition	√	√	√	√	-	-	-
				Body and subsidiary system	ABS-Traction Control (Antiblock Brake)System	√	√	√	√	√	-	-
					BAS-Brake Assist System	√	√	√	√	-	-	-
					EAG-Automatic Transmission(ETC.5,ETC.6)	√	√	√	√	√	-	-
					PML-Vehicle speed sensing steering system	√	√	√	-	-	-	-
				Climate control	AB-Airbag	√	√	√	√	-	-	-
					APS-Automatic navigation system	√	√	√	-	-	-	-
					ATA-Anti-theft system	√	√	√	√	√	-	-
					KI-Instrument cluster	√	√	√	√	√	√	-
					LWR-Headlight range adjustment	√	√	√	-	-	-	-
					PSE-Pneumatic control unit	√	√	√	-	-	-	-
					PTS-PARKTRONIC	√	√	√	√	√	-	-
					RFL(Driving authorization system2b)-Radio frequency locking system	√	√	√	-	-	-	-
					TELE AID-TELEA	√	√	√	-	-	-	-
				Chassis	KFB CF-Comfort System	√	√	√	√	√	-	-
					HAU-Air conditioning system	√	√	√	-	-	-	-
				Drive	KLA-Air conditioning system	√	√	√	√	√	-	-
					STH-Park heating	√	√	√	-	-	-	-
					Transmission	√	√	√	√	√	√	-
					ESM-Electronic selector module	√	√	√	√	√	-	-
					HFM-SFI-Hot film engine management	√	√	√	√	-	-	-
					ME2-SFI-Motor electronics	√	√	√	√	-	√	-
					VG-Transfer case	√	√	√	√	-	-	-
Chassis	Traction systems ABS,ASR,ETS,ESP	√	√		√	√	-	-	-			
	BAS-Brake assist	√	√		√	√	√	-	-			
Body	AB-Airbag	√	√		√	√	-	√	-			
	AAM-All Activity Module	√	√	√	√	√	√	-				
	EAM-Extended activity module (As of model year 2000)	√	√	√	√	-	-	-				
	DAS-Drive authorization sys-tem(As of model year 2000)	√	√	√	√	-	-	-				
	LCP-Lower operating panel with power window function (As of model year 2002)	√	√	√	√	√	-	-				
	SEM-Security Module(Up to module year 1999)	√	√	√	-	-	-	-				
	HRA-Headlamp range adjust-ment(As of model year 2000)	√	√	√	√	-	-	-				
Information and comm-unication	ICM-Instrument cluster with maintenance interval display	√	√	√	√	√	√	-				
	PTS-Parktronic system	√	√	√	√	√	-	-				
Air condi-tioning	AAC-Automatic air condition-ing(As of model year 2002)	√	√	√	√	√	-	-				
Drive	Transmission	√	√	√	√	-	√	-				
	ISM - Intelligent servo module ( Drive train CAN bus )	√	√	√	√	-	-	-				
	ME 9.7 - Motor electronics 9.7	√	√	√	√	√	√	-				
	Chassis	AIRmatic	√	√	√	√	√	-	-			
		ESP - Electronic stability program	√	√	√	√	√	√	-			
		TPC - Tire pressure monitor	√	√	√	√	-	-	-			
		EHPS - Electrical power steering	√	√	√	√	-	-	-			

Benz	-	≥	164	Body	AB - Airbag	√	√	√	√	-	√	-
					WSS - Weight sensing system	√	√	√	√	-	-	-
					RevETR-LF - Left front reversible emergency tensioning retractor	√	√	√	√	-	-	-
					RevETR-RF - Right front reversible emergency tensioning retractor	√	√	√	√	-	-	-
					EZS - Electronic ignition switch	√	√	√	√	-	√	-
					CGW - Central gateway	√	√	√	-	-	-	-
					KG - Keyless Go	√	√	√	√	-	-	-
					HRA - Headlamp range adjustment	√	√	√	√	√	-	-
					OCP - Overhead control panel	√	√	√	√	√	-	-
					UCP - Upper control panel	√	√	√	√	√	-	-
					HBF (Rear control panel) - Rear control field	√	√	√	√	√	-	-
					SAM-F - Signal acquisition and actuation module front	√	√	√	√	-	-	-
					REAR SAM - Rear signal acquisition and actuation module	√	√	√	√	√	-	-
					System diagnosis (only interior CAN fault)	√	√	√	-	-	-	-
				Information and communication	IC - Instrument cluster	√	√	√	√	√	√	-
					ASSYST Active Service System	√	√	√	√	-	√	-
					ASSYST PLUS - PLUS Active Service System	√	√	√	√	-	√	-
					SCM [MRM] - Steering column module	√	√	√	√	√	-	-
					PTS - Parktronic system	√	√	√	√	-	-	-
					COMAND or AUDIO	√	√	√	√	√	√	-
					CDC - CD changer	√	√	√	√	-	-	-
					SOUND - Sound system	√	√	√	√	√	-	-
				Seats and doors	DCM-FL - Door control module front left	√	√	√	√	√	-	-
					DCM-FR - Door control module front right	√	√	√	√	√	-	-
					REDC - Rear-end door closing control module	√	√	√	√	-	-	-
					ESA driver - Electric seat adjustment driver (with memory)	√	√	√	√	√	-	-
					ESA passenger - Electric seat adjustment front passenger (with memory)	√	√	√	√	√	-	-
					DS-LF - Left front dynamic seat	√	√	√	√	√	-	-
					DS-RF - Right front dynamic seat	√	√	√	√	√	-	-
					DSP - Pneumatic pump for dynamic seat	√	√	√	√	√	-	-
				Air conditioning	HS - Seat heater	√	√	√	√	√	-	-
					AAC - Automatic air conditioning	√	√	√	√	√	-	-
					STH - Stationary heater with remote control	√	√	√	√	-	-	-
Benz	-	≥	166	Drive	HSW - Heated steering wheel	√	√	√	-	-	-	-
					ME - Motor electronics 'MED177'	√	√	√	√	-	-	-
					VGSNAG2 (722.9) - Fully integrated transmission control (Y3/8n4)	√	√	√	√	-	-	-
					ISM - Shift module (A80)	√	√	√	√	-	-	-
					FSCU_EC - Control unit Fuel pump (N118)	√	√	√	√	-	-	-
					IRS-HRA - Outer right rear intelligent radar sensor system (B29/5)	√	√	√	√	-	-	-
				Chassis	IRS-HLA - Outer left rear intelligent radar sensor system (B29/4)	√	√	√	√	-	-	-
					ESP - Electronic stability program (N30/4)	√	√	√	√	-	-	-
					EFB - Electric parking brake (N128)	√	√	√	√	-	-	-
					RDK - Tire pressure monitor (N88)	√	√	√	√	-	-	-
				BODY	ES - Electrical power steering (N68)	√	√	√	√	-	-	-
					EZS - Electronic ignition lock	√	√	√	√	-	-	-
					SRS - Airbag	√	√	√	√	-	-	-
					KG - KEYLESS GO	√	√	√	√	-	-	-
SG-SW- Control unit 'Headlamp' (N71/1)	√	√	√		√	-	-	-				
SAM - Signal acquisition and actuation module (N10)	√	√	√		√	-	-	-				
RevETR-LF - Left front reversible emergency tensioning retractor (A76)	√	√	√		√	-	-	-				
RevETR-RF - Right front reversible emergency tensioning retractor (A76/1)	√	√	√		√	-	-	-				
ZBE - Operating unit of control unit 'Audio or COMAND' (A40/9)	√	√	√		√	-	-	-				
Trailer recognition module - Trailer recognition (N28/1)	√	√	√		√	-	-	-				
	Rear - Rear control unit (N10/8)	√	√	√	√	-	-	-				
	SD - Control module 'Sliding roof (A98/1)'	√	√	√	√	-	-	-				
	IC - Instrument cluster	√	√	√	√	-	-	-				
	MFK - Multifunction camera (A40/11)	√	√	√	√	-	-	-				

				Information and communication	RFK- Backup camera (B84/3)	√	√	√	√	-	-	-	
					SCCM - Steering column module (N80)	√	√	√	√	-	-	-	
					mbrace - mbrace (N123/4)	√	√	√	√	-	-	-	
					SDAR - Satellite Radio(USA)	√	√	√	√	-	-	-	
					UCI - Media interface (N125/1)	√	√	√	√	-	-	-	
					ZAN - Audio/COMAND display (A40/8)	√	√	√	√	-	-	-	
					Seats and doors	DCU-LF - Left front door (N69/1)	√	√	√	√	-	-	-
						DCU-RF - Right front door (N69/2)	√	√	√	√	-	-	-
						DCU-LR - Left rear door (N69/3)	√	√	√	√	-	-	-
						DCU-RR - Right rear door (N69/4)	√	√	√	√	-	-	-
						ESA'Driver' - Electrical seat adjustment 'Driver' with memory function (N32/1)	√	√	√	√	-	-	-
						ESA 'Front passenger' - Electrical seat adjustment 'Front passenger' with memory	√	√	√	√	-	-	-
					Air conditioning	HKS - Tailgate control (N121/1)	√	√	√	√	-	-	-
AAC - Air conditioning	√	√	√	√		-	-	-					
Benz	-	A	168	Drive	ECM - Engine control monolith	√	√	√	√	-	-	-	
					CDI - Common Rail Diesel Injection	√	√	√	√	-	-	-	
				Chassis	ACS - Automatic clutch system	√	√	√	√	-	-	-	
					FTC - Front transmission control	√	√	√	√	-	-	-	
					GRM - Gear recognition module	√	√	√	√	√	-	-	
				Body	AB - Airbag	√	√	√	√	-	√	-	
					LCP - Lower control panel	√	√	√	√	-	-	-	
					ATA - Anti-theft alarm system	√	√	√	√	-	-	-	
					RFL - Radio frequency locking/electric central locking	√	√	√	√	-	-	-	
				Information and communication	ICM - Instrument cluster with maintenance interval display	√	√	√	√	√	√	-	
					PTS - Parktronic system	√	√	√	√	-	-	-	
				Seats and doors	DCM-FL - Door control module front left	√	√	√	√	-	-	-	
					DCM-FR - Door control module front right	√	√	√	√	-	-	-	
DCM-RL - Door control module rear left	√	√	√		√	-	-	-					
DCM-RR - Door control module rear right	√	√	√		√	-	-	-					
Air conditioning	STH - Stationary heater	√	√	√	√	-	-	-					
	TAC - Automatic temperature control	√	√	√	-	-	-	-					
Benz	-	A	169	Drive	ESM - Electronic selector module	√	√	√	√	√	-	-	
					CVT - Continuously variable automatic transmission	√	√	√	√	-	√	-	
					ME-SFI - Motor electronics	√	√	√	√	√	-	-	
				Chassis	ESP - Electronic stability program	√	√	√	√	-	√	-	
					ES - Electrical power steering	√	√	√	√	-	-	-	
				Body	EZS - Electronic ignition switch ( Without Keyless Go )	√	√	√	√	-	√	-	
					OCP - Overhead control panel	√	√	√	√	√	-	-	
					SAM - Signal acquisition and actuation module	√	√	√	√	√	-	-	
				Information and communication	IC - Instrument cluster with maintenance interval display	√	√	√	√	√	√	-	
					SCM [MRM] - Steering column module	√	√	√	√	√	-	-	
					PTS - Parktronic system	√	√	√	√	-	-	-	
				Seats and doors	DCM-FL - Door control module front left	√	√	√	√	√	-	-	
					DCM-FR - Door control module front right	√	√	√	√	√	-	-	
DCM-RL - Door control module rear left	√	√	√		√	√	-	-					
DCM-RR - Door control module rear right	√	√	√		√	√	-	-					
Air conditioning	C-ACC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	√	√	-	-					
Benz	-	SLK	170-SLK(38-pin diagn	Gasoline engine	ETC - Electronic transmission control	√	√	√	√	√	-	-	
					HFM-SFI - Hot film engine management	√	√	√	√	√	√	-	
					ME2-SFI - Motor electronics 2	√	√	√	√	√	-	-	
				Chassis & Drivetrain	Traction systems ABS, ASR, ETS, ESP	√	√	√	√	√	-	-	
					BAS - Brake assist	√	√	√	√	-	-	-	
					AB - Airbag	√	√	√	√	-	-	-	
					RFL - Radio frequency locking/electric central locking	√	√	√	-	√	-	-	
					RFL (DAS2) - Radio frequency locking (drive authorization stage 2)	√	√	√	-	√	-	-	
PSE - Pneumatic system equipment	√	√	√	√	-	-	-						
ATA - Anti-theft alarm system	√	√	√	√	√	-	-						

			ostic socket)	Body & Accessories	ICM - Instrument cluster with maintenance interval display	√	√	√	√	√	√	-				
					D2B - AUDIO	√	√	√	√	√	-	-				
					CDC - CD changer	√	√	√	√	√	-	-				
					VCS - Voice control system	√	√	√	√	√	-	-				
					CTEL - Cellular telephone 1 (fixed installation or portable) ( D2B )	√	√	√	√	√	-	-				
				Climate control	AAC	√	√	√	√	√	-	-				
					Transmission	√	√	√	√	√	√	-				
Benz	-	SLK	171	Drive	ESM-electronic shift module	√	√	√	√	-	-	-				
					ME-SFI-engine system	√	√	√	√	-	√	-				
					ESP-Electronic Stability Program	√	√	√	√	-	√	-				
				Chassis	AB-Airbag	√	√	√	√	-	√	-				
					CGW-central gateway	√	√	√	-	-	-	-				
					EZS-electronic ignition switch	√	√	√	√	-	√	-				
					VR-Convertible top	√	√	√	√	√	-	-				
					HRA-headlight range adjustment	√	√	√	√	√	-	-				
					OCP-Top Control Panel	√	√	√	√	√	-	-				
					UCP-top control panel	√	√	√	√	√	-	-				
					SAM-F-front signal input and output module	√	√	√	√	-	-	-				
					REAR SAM-rear signal input and output modules	√	√	√	-	-	-	-				
					System diagnostics-system diagnosis	√	√	√	-	-	-	-				
				Information and communication	IC-dash-board	√	√	√	√	√	√	-				
					ASSYST-active maintenance system	√	√	√	√	-	√	-				
					ASSYST PLUS-active maintenance system	√	√	√	√	-	√	-				
					SCM-steering column module	√	√	√	-	-	-	-				
					PTS-parking electronic systems.	√	√	√	-	-	-	-				
				Seats and doors	DCM-L-left door control module	√	√	√	√	√	-	-				
					DCM-R-Right Door Control Module	√	√	√	√	√	-	-				
ESA driver-driver electronic seat adjustment (with memory)	√	√	√		-	-	-	-								
ESA passenger-front passenger electronic seat adjustment(with memory)	√	√	√		-	-	-	-								
HS-seat heaters	√	√	√		-	-	-	-								
Air conditioning	C-AAC-comfort automatic air conditioning/AAC-automatic air conditioning/HEAT-automatic heater	√	√	√	√	-	-	-								
	HSW-heated steering wheel	√	√	√	-	-	-	-								
Benz	Up to 05/97	C	202	Engine	HFMSFI,ME2	√	√	√	√	-	-	-				
				Chassis	Traction	√	√	√	√	-	-	-				
					BAS	√	√	√	√	-	-	-				
				Body	ETC.6	√	√	√	√	-	-	-				
					AB	√	√	√	√	-	-	-				
					IC	√	√	√	√	√	√	-				
				Climate Control	HRA	√	√	√	√	√	-	-				
AAC,TAC	√	√	√		√	-	-	-								
				Drive	ETC - Electronic transmission control	√	√	√	√	-	-	-				
					ESM - Electronic selector module	√	√	√	√	√	-	-				
					HFM-SFI - Hot film engine management/ME2-SFI - Motor electronics	√	√	√	√	-	-	-				
				Chassis	Traction systems ABS, ASR, ETS, ESP	√	√	√	√	√	-	-				
					BAS - Brake assist	√	√	√	√	-	-	-				
				Body	AB - Airbag	√	√	√	√	-	-	-				
					OCP - Overhead control panel	√	√	√	√	-	-	-				
					EZS - Electronic ignition switch ELCODE	√	√	√	√	-	-	-				
					PSE - Pneumatic system equipment	√	√	√	√	-	-	-				
					SAM - Signal acquisition and actuation module	√	√	√	√	-	-	-				
					LCP - Lower control panel	√	√	√	√	-	-	-				
					HRA - Headlamp range adjustment	√	√	√	√	√	-	-				
				MSS - Special vehicle multifunction control module	√	√	√	-	-	-	-					
				As d					ICM - Instrument cluster with maintenance interval display	√	√	√	√	√	√	-
									D2B - AUDIO	√	√	√	√	√	-	-
CDC - CD changer	√	√	√						-	-	-	-				

Benz	f 06/97, DAS 3	C	202	Information and communication	VCS - Voice control system	√	√	√	-	-	-	-
					CTEL - Cellular telephone 1 (fixed installation or portable) ( D2B )	√	√	√	-	-	-	-
					APS - Auto pilot system	√	√	√	-	-	-	-
					PTS - Parktronic system	√	√	√	√	√	-	-
					TELE AID, E-call or cellular telephone - Emergency call system ( K-wire )	√	√	√	√	√	-	-
					DN - Dynamic navigation by means of CTEL ( K-wire )	√	√	√	-	-	-	-
				Seats and doors	DCM1 - Door control module front driver side	√	√	√	√	-	-	-
					DCM2 - Door control module front passenger side	√	√	√	√	-	-	-
					DCM3 - Door control module rear driver side	√	√	√	√	-	-	-
					DCM4 - Door control module rear passenger side	√	√	√	√	-	-	-
					ESA-FL - Electric seat adjustment front left	√	√	√	√	-	-	-
ESA-FR - Electric seat adjustment front right	√	√	√		√	-	-	-				
Air conditioning	TAC - Automatic temperature control/AAC - Automatic air conditioning	√	√	√	√	-	-	-				
Benz	Up to 08/2003	C	203	Drive	Transmission	√	√	√	√	√	√	-
					ESM - Electronic selector module	√	√	√	√	√	-	-
					DTR - DISTRONIC	√	√	√	-	-	-	-
					ME-SFI - Motor electronics	√	√	√	√	-	√	-
				Chassis	ESP - Electronic stability program	√	√	√	√	√	√	-
					BAS - Brake assist	√	√	√	√	√	-	-
					VP - Vacuum pump brake booster	√	√	√	√	√	-	-
				Body	EZS - Electronic ignition switch	√	√	√	√	-	√	-
					AB - Airbag	√	√	√	√	-	√	-
					SAM-F - Signal acquisition and actuation module front	√	√	√	√	√	-	-
					REAR SAM - Rear signal acquisition and actuation module	√	√	√	√	√	√	-
					HRA-FL - Front left headlamp range control	√	√	√	√	-	-	-
					HRA-FR - Front right headlamp range control	√	√	√	√	√	-	-
					OCP - Overhead control panel	√	√	√	√	√	√	-
					UCP - Upper control panel	√	√	√	√	√	-	-
				Information and communication	LCP - Lower control panel	√	√	√	-	√	-	-
					AHE - Trailer recognition	√	√	√	√	√	-	-
					ICM - Instrument cluster with maintenance interval display	√	√	√	√	√	√	-
					SCM [MRM] - Steering column module(As of model year 2002)	√	√	√	√	√	-	-
					PTS - Parktronic system	√	√	√	√	√	-	-
					D2B - COMAND or AUDIO	√	√	√	√	√	-	-
CDC - CD changer	√	√	√		-	-	-	-				
Seats and doors	DCM-FL - Door control module front left	√	√		√	√	√	√	-			
	DCM-FR - Door control module front right	√	√		√	√	√	√	-			
	DCM-RL - Door control module rear left	√	√		√	√	√	√	-			
	DCM-RR - Door control module rear right	√	√	√	√	√	√	-				
	ESA driver - Electric seat adjustment driver(with memory)	√	√	√	√	√	√	-				
	ESA passenger - Electric seat adjustment front passenger (with memory)	√	√	√	√	√	√	-				
Air conditioning	C-AAC - Convenience automatic air conditioning/AAC - Automatic air conditioning/HEAT - Automatic heater	√	√	√	√	√	-	-				
Benz		C		Drive	Transmission	√	√	√	√	√	√	-
					ESM - Electronic selector module	√	√	√	√	√	-	-
					ME-SFI - Motor electronics	√	√	√	√	-	√	-
				Chassis	ESP - Electronic stability program	√	√	√	√	-	√	-
					CGW - Central gateway	√	√	√	-	-	-	-
					EZS - Electronic ignition switch	√	√	√	√	-	√	-
					AB - Airbag	√	√	√	√	-	√	-
					WSS - Weight sensing system(USA)	√	√	√	√	-	-	-
					SAM-F - Signal acquisition and actuation module front	√	√	√	√	-	√	-

Benz	From 09/2003 to 12/2007	C	203	Body	REAR SAM - Rear signal acquisition and actuation module	√	√	√	√	-	√	-
					HRA-FL - Front left headlamp range control	√	√	√	√	-	-	-
					HRA-FR - Front right headlamp range control	√	√	√	√	√	-	-
					OCP - Overhead control panel	√	√	√	√	√	√	-
					UCP - Upper control panel	-	√	√	√	√	√	-
					LCP - Lower control panel	√	√	√	√	√	-	-
					MSS - Special vehicle multifunction control module	√	√	√	√	-	-	-
				Information and communication	ICM - Instrument cluster with maintenance interval display	√	√	√	√	-	√	-
					SCM [MRM] - Steering column module	√	√	√	√	-	-	-
					PTS - Parktronic system	√	√	√	√	√	-	-
				Seats and doors	Audio, video, navigation and telematics	√	√	√	√	-	-	-
					DCM-FL - Door control module front left	√	√	√	√	√	√	-
					DCM-FR - Door control module front right	√	√	√	√	√	√	-
					DCM-RL - Door control module rear left	√	√	√	√	√	√	-
					DCM-RR - Door control module rear right	√	√	√	√	√	√	-
					ESA driver - Electric seat adjustment driver(with memory)	√	√	√	√	√	√	-
				Air conditioning	ESA passenger - Electric seat adjustment front passenger (with memory)	√	√	√	√	√	√	-
					C-AAC - Convenience automatic air conditioning/AAC - Automatic air conditioning/HEAT - Automatic heater	√	√	√	√	√	-	-
					STH - Stationary heater with remote control	√	√	√	√	-	-	-
				Drive	ME-SFI-engine system (CAN bus chassis)	√	√	√	√	√	√	-
FSCU-fuel pump (power CAN bus)	√	√	√		√	√	-	-				
ETC - Transmission	√	√	√		√	-	-	-				
ESM[EWM] - Electronic selector module	√	√	√		√	√	-	-				
Chassis	ABR - adaptive brake	√	√	√	√	-	√	-				
	Suspension - suspension (chassis CAN bus)	√	√	√	√	√	-	-				
Body	TPM - Tire pressure monitor	√	√	√	√	-	-	-				
	CGW-central gateway (central CAN bus)	√	√	√	√	-	-	-				
	EZS - Electronic ignition lock	√	√	√	√	-	-	-				
	KG - KEYLESS GO	√	√	√	-	-	-	-				
	XALWA-L - Left xenon headlamp	√	√	√	√	√	-	-				
	XALWA-R - Right xenon headlamp	√	√	√	√	√	-	-				
	AB - Airbag	√	√	√	√	-	-	-				
	Driver-side SAM - Front signal acquisition and actuation module(N10/1)	√	√	√	√	√	-	-				
	WBS - Hazard warning switch	√	√	√	√	-	-	-				
	WSS - Weight sensing system(N110)	√	√	√	√	-	-	-				
	Rear SAM - Rear signal acquisition and actuation module(N10/2)	√	√	√	√	√	-	-				
	OCP - Overhead control panel(N70)	√	√	√	√	√	√	-				
	ZBE - Operating unit of control unit 'Audio or COMAND'	√	√	√	√	-	-	-				
	RevETR-LF - Left front reversible emergency tensioning retractor(A76)	√	√	√	√	-	-	-				
RevETR-RF - Reft front reversible emergency tensioning retractor(A76/1)	√	√	√	√	-	-	-					
Information and communication	IC - Instrument cluster(A1)	√	√	√	√	√	√	-				
	SCM [MRM] - steering column module (chassis CAN bus)	√	√	√	√	√	-	-				
	PTS - PARKTRONIC(N62)	√	√	√	√	√	-	-				
	COMAND - COMAND APS(A40/3)	√	√	√	√	√	-	-				
	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	√	√	√	√	√	-	-				
	TV - TV tuner(A90/1)	√	√	√	√	-	-	-				
	SDAR - Satellite Radio(USA)	√	√	√	√	√	-	-				
Seats and doors	ZAN - Audio/COMAND display	√	√	√	√	-	-	-				
	DCM-LF - Left front door(N69/1)	√	√	√	√	√	-	-				
	DCM-RF - Right front door(N69/2)	√	√	√	√	√	-	-				
	DCM-LR - Left rear door(N69/3)	√	√	√	√	√	-	-				
	DCM-RR - Right rear door(N69/4)	√	√	√	√	√	-	-				
ESA'Driver' - Electric seat adjustment 'Driver'	√	√	√	√	√	-	-					

				Air conditioning	AAC - Air conditioning(N22/7)	√	√	√	√	√	-	-
Benz	-	E Coupe	207	Drive	ME2-SFI - Motor electronics2	√	√	√	√	√	-	-
					Fuel pump	√	√	√	-	-	-	-
					ESM-Electronic selector module	√	√	√	√	√	-	-
					ISM-Shift module	√	√	√	√	-	-	-
				Chassis	ESP-Electronic stability program	√	√	√	√	√	-	-
					ADS-Adaptive damping system(N51/5)	√	√	√	√	√	-	-
				Body	TPC-Tire pressure monitor	√	√	√	√	-	-	-
					CGW[ZGW]-Central gateway	√	√	√	√	-	-	-
					EZS-Electronic ignition lock	√	√	√	√	-	-	-
					KG-Keyless Go	√	√	√	√	√	-	-
					SRS-Supplemental restraint system(N2/10)	√	√	√	√	-	-	-
					WSS-Weight sensing system(N110)	√	√	√	√	-	-	-
					OCP-Overhead control panel(N70)	√	√	√	√	√	-	-
					PSD-Control mudule'Panoramic sliding roof'(A98)	√	√	√	√	√	-	-
					Driver-side SAM-Driver signal acquisiton and actuation module	√	√	√	√	√	-	-
					Rear SAM-Rear signal acquisiton and actuation module	√	√	√	√	√	-	-
					BSN-Battery sensor	√	√	√	√	-	-	-
					RevETR-LF-Left front reversible emergency tensioning retractor	√	√	√	√	-	-	-
					RevETR-RF-Right front reversible emergency tensioning retractor	√	√	√	√	-	-	-
					XALWAL-L-Xenon headlamp,left	√	√	√	√	√	-	-
					XALWAL-R-Xenon headlamp,right	√	√	√	√	√	-	-
					Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√	√	√
				PTS-PARKTRONIC(N62)		√	√	√	√	√	-	-
				SCCM-Steering column module(N80)		√	√	√	√	√	-	-
				COMAND or AUDIO		√	√	√	√	√	√	-
				COU[ZBE]-Central operating unit		√	√	√	√	√	-	-
				Central display		√	√	√	√	-	-	-
				MFK-Multifunction camera		√	√	√	√	√	-	-
				TELE AID-Telematic services Emergency call		√	√	√	√	-	-	-
				TELE AID-Telematic services MB Info,Roadside assistance(USA,Canada),Tele diagnosis(ECE)		√	√	√	-	-	-	-
				TELE AID-Telematic services Stolen vehicle tracking		√	√	√	√	-	-	-
				Seats and doors	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√	-	-	-
DCU-LF_ Left front door	√	√	√		√	√	-	-				
DCU-RF_ Right front door	√	√	√		√	√	-	-				
DCU-LR_ Left rear door	√	√	√		√	√	-	-				
DCU-RR_ Left rear door	√	√	√		√	√	-	-				
Trunk lid control	√	√	√		√	√	-	-				
ESA'Driver'-Electric seat adjustment'Driver'(N32/1)	√	√	√		√	√	-	-				
ESA'Front passenger'-Electric seat adjustment'Front passenger'	√	√	√		√	√	-	-				
Air conditionin g	SIH-FOND-Rear passenger compartment seat heater	√	√	√	√	-	-	-				
	Drive	AAC-Air conditioinig	√	√	√	√	√	-	-			
		Transmission	√	√	√	√	-	-	-			
		HFM-SFI-Hot film engine management	√	√	√	√	-	-	-			
	Chassis	ME2-SFI-Motor electronics 2	√	√	√	√	-	√	-			
		Traction systems ABS,ASR,ETS,ESP	√	√	√	√	√	√	-			
		BAS-Brake assist	√	√	√	√	√	-	-			
		VP-Vacuum pump brake booster	√	√	√	√	√	-	-			
		AB-Airbag	√	√	√	√	-	-	-			
		OCP-Overhead control panel	√	√	√	√	-	-	-			
		EZS-Electronic ignition switch ELCODE	√	√	√	√	-	-	-			
PSE-Pneumatic system equipment	√	√	√	√	-	-	-					

Benz	-	CLK	208	Body	SAM-Signal acquisition and actuation module	√	√	√	√	-	-	-
					RVC-Rollover bar soft top control module	√	√	√	√	√	-	-
					LCP-Lower control panel	√	√	√	√	-	-	-
					HRA-Headlamp range adjustment(35#)	√	√	√	√	√	√	-
				Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√	-	√	-
					D2B-COMAND or AUDIO(33#)	√	√	√	√	-	-	-
					CDC-CD changer(33#)	√	√	√	-	-	-	-
					CTEL-Cellular telephone 1(fixed installation or portable)(D2B)(33#)	√	√	√	-	-	-	-
				Seats and doors	PTS-Parktronic system	√	√	√	√	-	-	-
					DCM1-Door control module front driver side	√	√	√	√	√	√	√
					DCM2-Door control module front passenger side	√	√	√	√	√	√	√
					ESA-FL-Electric seat adjustment front left	√	√	√	√	-	√	-
				Air conditioning	ESA-FR-Electric seat adjustment front right	√	√	√	√	-	√	-
TAC-Automatic temperature control/AAC-Automatic air conditioning	√	√	√	√	√	√	-					
Drive	ETC-Electronic Transmission	√	√	√	√	-	-	-				
	ESM-electronic shift module	√	√	√	√	√	-	-				
	DTR-distance control	√	√	√	-	-	-	-				
	ME-SFI-engine system	√	√	√	√	-	√	-				
Chassis	ESP-Electronic Stability Program	√	√	√	√	-	√	-				
Body	AB-Airbag	√	√	√	√	-	-	-				
	OCP-Top Control Panel	√	√	√	√	√	-	-				
	EZS-electronic ignition switch	√	√	√	√	-	-	-				
	HRA-FL-left front headlight adjustment	√	√	√	√	-	-	-				
	HRA-FR-right front headlight adjustment	√	√	√	√	√	-	-				
	LCP-lower control panel	√	√	√	√	√	-	-				
	UCP-top control panel	√	√	√	√	√	-	-				
	SAM-F-front signal input / output module	√	√	√	√	√	-	-				
	REAR SAM-rear signal input / output module	√	√	√	√	√	-	-				
	RVC - Rollover bar soft top control module	√	√	√	√	√	-	-				
AHE-trailer identification	AHE-trailer identification	√	√	√	√	√	-	-				
Information and communication	ICM-dashboard with maintenance reminders	√	√	√	√	-	√	-				
	SCM[MRM] - Steering column module	√	√	√	√	√	√	-				
	PTS-parking assist system	√	√	√	√	√	-	-				
	D2B-COMMAND or audio	√	√	√	√	-	-	-				
Seats and doors	CDC-CD drive	√	√	√	-	-	-	-				
	DCM-L-left door control module	√	√	√	√	-	-	-				
	DCM-R-Right Door Control Module	√	√	√	√	-	-	-				
	RCM-back control module	√	√	√	√	-	-	-				
	ESA driver - Electric seat adjustment driver(with memory)	√	√	√	√	√	-	-				
Air conditioning	ESA passenger - front passenger seat adjustment (with memory)	√	√	√	√	√	-	-				
C-AAC/AAC/HEAT- automatic air conditioning system	√	√	√	√	√	-	-					
Engine	HFMSFI	√	√	√	√	-	-	-				
	ME2	√	√	√	√	-	-	-				
	ME1RE	√	√	√	√	-	-	-				
	DM	√	√	√	√	-	√	-				
	EA,CC,ISC	√	√	√	√	√	-	-				
Chassis	Traction	√	√	√	√	-	-	-				
	BAS	√	√	√	√	-	-	-				
	ETC.6,ETC.5	√	√	√	√	-	-	-				
	SPS	√	√	√	√	-	-	-				
Body	CF	√	√	√	√	-	-	-				
	PSE	√	√	√	√	-	-	-				
	ATA	√	√	√	√	√	-	-				
	AB	√	√	√	√	-	-	-				
	IC	√	√	√	√	√	√	-				
	HRA	√	√	√	-	-	-	-				
Climate Control	PTS	√	√	√	√	√	-	-				
AAC,TAC	√	√	√	√	-	-	-					
Benz	-	CLK	209	Drive	ETC-Electronic Transmission	√	√	√	√	-	-	-
					ESM-electronic shift module	√	√	√	√	√	-	-
					DTR-distance control	√	√	√	-	-	-	-
					ME-SFI-engine system	√	√	√	√	-	√	-
				Chassis	ESP-Electronic Stability Program	√	√	√	√	-	√	-
				Body	AB-Airbag	√	√	√	√	-	-	-
					OCP-Top Control Panel	√	√	√	√	√	-	-
					EZS-electronic ignition switch	√	√	√	√	-	-	-
					HRA-FL-left front headlight adjustment	√	√	√	√	-	-	-
					HRA-FR-right front headlight adjustment	√	√	√	√	√	-	-
					LCP-lower control panel	√	√	√	√	√	-	-
					UCP-top control panel	√	√	√	√	√	-	-
					SAM-F-front signal input / output module	√	√	√	√	√	-	-
REAR SAM-rear signal input / output module	√	√	√		√	√	-	-				
RVC - Rollover bar soft top control module	√	√	√		√	√	-	-				
AHE-trailer identification	√	√	√	√	√	-	-					
Information and communication	ICM-dashboard with maintenance reminders	√	√	√	√	-	√	-				
	SCM[MRM] - Steering column module	√	√	√	√	√	√	-				
	PTS-parking assist system	√	√	√	√	√	-	-				
	D2B-COMMAND or audio	√	√	√	√	-	-	-				
Seats and doors	CDC-CD drive	√	√	√	-	-	-	-				
	DCM-L-left door control module	√	√	√	√	-	-	-				
	DCM-R-Right Door Control Module	√	√	√	√	-	-	-				
	RCM-back control module	√	√	√	√	-	-	-				
	ESA driver - Electric seat adjustment driver(with memory)	√	√	√	√	√	-	-				
Air conditioning	ESA passenger - front passenger seat adjustment (with memory)	√	√	√	√	√	-	-				
C-AAC/AAC/HEAT- automatic air conditioning system	√	√	√	√	√	-	-					
Engine	HFMSFI	√	√	√	√	-	-	-				
	ME2	√	√	√	√	-	-	-				
	ME1RE	√	√	√	√	-	-	-				
	DM	√	√	√	√	-	√	-				
Chassis	EA,CC,ISC	√	√	√	√	√	-	-				
	Traction	√	√	√	√	-	-	-				
	BAS	√	√	√	√	-	-	-				
	ETC.6,ETC.5	√	√	√	√	-	-	-				
Body	SPS	√	√	√	√	-	-	-				
	CF	√	√	√	√	-	-	-				
	PSE	√	√	√	√	-	-	-				
	ATA	√	√	√	√	√	-	-				
	AB	√	√	√	√	-	-	-				
	IC	√	√	√	√	√	√	-				
Climate Control	HRA	√	√	√	-	-	-	-				
PTS	√	√	√	√	√	-	-					
AAC,TAC	√	√	√	√	-	-	-					
Benz	-	E	210	Engine	HFMSFI	√	√	√	√	-	-	-
					ME2	√	√	√	√	-	-	-
					ME1RE	√	√	√	√	-	-	-
					DM	√	√	√	√	-	√	-
				Chassis	EA,CC,ISC	√	√	√	√	√	-	-
					Traction	√	√	√	√	-	-	-
					BAS	√	√	√	√	-	-	-
					ETC.6,ETC.5	√	√	√	√	-	-	-
				Body	SPS	√	√	√	√	-	-	-
					CF	√	√	√	√	-	-	-
					PSE	√	√	√	√	-	-	-
					ATA	√	√	√	√	√	-	-
					AB	√	√	√	√	-	-	-
IC	√	√	√		√	√	√	-				
Climate Control	HRA	√	√	√	-	-	-	-				
PTS	√	√	√	√	√	-	-					
AAC,TAC	√	√	√	√	-	-	-					



Benz	As of 03/97 DAS 3	m	210	Drive	Transmission	√	√	√	√	-	-	-
					ESM - Electronic selector module	√	√	√	√	√	-	-
					HFM-SFI - Hot film engine management	√	√	√	√	-	-	-
					ME2-SFI - Motor electronics 2	√	√	√	√	-	-	-
				Chassis	Traction systems ABS, ASR, ETS, ESP	√	√	√	√	-	-	-
					SPS - Speed-sensitive power steering	√	√	√	√	-	-	-
				Body	AB - Airbag	√	√	√	√	-	-	-
					OCP - Overhead control panel	√	√	√	√	-	-	-
					EZS - Electronic ignition switch ELCODE	√	√	√	√	-	-	-
					PSE - Pneumatic system equipment	√	√	√	√	-	-	-
					SAM - Signal acquisition and actuation module	√	√	√	√	-	-	-
					LCP - Lower control panel	√	√	√	√	-	-	-
				Information and communication	MSS - Special vehicle multifunction control module	√	√	√	√	-	-	-
					ICM - Instrument cluster with maintenance interval display	√	√	√	√	√	√	-
				Seats and doors	DCM1 - Door control module front driver side	√	√	√	√	-	-	-
					DCM2 - Door control module front passenger side	√	√	√	√	-	-	-
					DCM3 - Door control module rear driver side	√	√	√	√	-	-	-
					DCM4 - Door control module rear passenger side	√	√	√	√	-	-	-
					ESA-FL - Electric seat adjustment front left	√	√	√	√	-	-	-
					ESA-FR - Electric seat adjustment front right	√	√	√	√	-	-	-
				Air conditioning	TAC - Automatic temperature control/AAC - Automatic air conditioning	√	√	√	√	-	-	-
Benz	Up to 05/2005	m	211	Drive	Transmission	√	√	√	√	√	-	-
					ESM-Electronic selector module	√	√	√	√	√	-	-
					DTR-Distronic	√	√	√	√	-	-	-
					ME-SFI-Motor electronics	√	√	√	√	-	√	-
				Chassis	SBC-Sensotronic Brake Control	√	√	√	√	-	√	-
					ESP-Electronic stability program	√	√	√	√	√	√	-
					Suspension	√	√	√	√	√	-	-
				Body	TPC-Tire pressure monitor	√	√	√	√	√	-	-
					CGW-Central gateway	√	√	√	-	-	-	-
					EZS-Electronic ignition switch/KG-Keyless Go(Special equipment)	√	√	√	√	√	-	-
					AB-Airbag	√	√	√	√	-	√	-
					WSS-Weight sensing system(USA)	√	√	√	√	-	-	-
					Dr-side SAM-Driver signal acquisition and actuation module	√	√	√	√	√	-	-
					Pass-side SAM-Passenger-side signal acquisition and actuation module	√	√	√	√	√	√	-
					REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	√	-	-
					HRA-Headlamp range adjustment	√	√	√	√	√	-	-
					OCP-Overhead control panel	√	√	√	√	√	√	-
					UCP-Upper control panel	√	√	√	√	√	-	-
					LCP-Lower control panel	√	√	√	√	√	-	-
					RevETR-LF- Left front reversible emergency tensioning retractor	√	√	√	-	-	-	-
					RevETR-RF-Right front reversible emergency tensioning retractor	√	√	√	-	-	-	-
On-board electrical system(voltage supply)	√	√	√		√	-	-	-				
BCM-Battery control module	√	√	√		√	√	-	-				
AHE-Trailer recognition	√	√	√		√	√	-	-				
MSS-Special vehicle multifunction control module	√	√	√	-	-	-	-					
Information and communication	System diagnosis	√	√	√	-	-	-	-				
	IC-Instrument cluster	√	√	√	√	√	√	-				
	ASSYST Active Service System	√	√	√	√	-	√	-				
	ASSYST PLUS-PLUS Active Service System	√	√	√	√	-	√	-				
SCM[MRM]-Steering column module	√	√	√	√	√	-	-					

Benz	m	211	Information and communication	PTS-Parktronic system	√	√	√	√	√	-	-	
				AGW-Audio Gateway	√	√	√	√	√	-	-	
				COMMAND/AUDIO-sound 50 or COMMAND	√	√	√	√	√	-	-	
				CDC-CD drive	√	√	√	√	-	-	-	
				HFS-hands-free system and microphone	√	√	√	-	-	-	-	
				CTEL-car phone	√	√	√	√	√	-	-	
				NAVI-navigation system (only with COMMAND combination of Japanese cars is invalid)	√	√	√	√	√	-	-	
				Seats and doors	DCM-FL-Door control module front left	√	√	√	√	√	√	-
					DCM-FR-Door control module front right	√	√	√	√	√	√	-
					DCM-RL-Door control module rear left	√	√	√	√	√	√	-
					DCM-RR-Door control module rear right	√	√	√	√	√	√	-
					TLC-Trunk lid control	√	√	√	√	√	-	-
					ESA driver-Electric seat adjustment driver(with memory)	√	√	√	√	√	-	-
					ESA passenger-Electric seat adjustment front passenger (with memory)	√	√	√	√	√	-	-
					HS-Seat heater	√	√	√	-	-	-	-
			DS-LF-Left front dynamic seat		√	√	√	√	√	-	-	
			DS-RF-Right front dynamic seat		√	√	√	√	√	-	-	
			DSP-Pneumatic pump for dynamic seat	√	√	√	√	√	-	-		
			Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning	√	√	√	√	√	-	-	
				HSW-Heated steering wheel	√	√	√	√	√	-	-	
				STH-Stationary heater with remote control	√	√	√	√	√	-	-	
			Drive	Transmission	√	√	√	√	√	-	-	
				ESM-Electronic selector module	√	√	√	√	√	-	-	
				DTR-Distronic	√	√	√	√	-	-	-	
			Chassis	ME-SFI-Motor electronics	√	√	√	√	-	√	-	
				SBC-Sensotronic Brake Control	√	√	√	√	-	√	-	
				ESP-Electronic stability program	√	√	√	√	√	√	-	
				Suspension	√	√	√	√	√	-	-	
			Body	TPC-Tire pressure monitor	√	√	√	√	√	-	-	
				CGW-Central gateway	√	√	√	-	-	-	-	
				EZS-Electronic ignition switch/KG Keyless Go(Special equipment)	√	√	√	√	√	-	-	
				AB-Airbag	√	√	√	√	-	√	-	
				WSS-Weight sensing system(USA)	√	√	√	√	-	-	-	
				Dr-side SAM-Driver signal acquisition and actuation module	√	√	√	√	√	-	-	
				Pass-side SAM-Passenger-side signal acquisition and actuation module	√	√	√	√	√	√	-	
				REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	√	-	-	
HRA-Headlamp range adjustment	√	√		√	√	√	-	-				
OCP-Overhead control panel	√	√		√	√	√	√	-				
UCP-Upper control panel	√	√		√	√	√	-	-				
LCP-Lower control panel	√	√		√	√	√	-	-				
RevETR-LF-Left front reversible emergency tensioning retractor	√	√		√	-	-	-	-				
RevETR-RF-Right front reversible emergency tensioning retractor	√	√		√	-	-	-	-				
On-board electrical system(voltage supply)	√	√		√	√	-	-	-				
Information and communication	BCM-Battery control module	√	√	√	√	√	-	-				
	AHE-Trailer recognition	√	√	√	√	√	-	-				
	MSS-Special vehicle multifunction control module	√	√	√	-	-	-	-				
	System diagnosis	√	√	√	-	-	-	-				
	IC-Instrument cluster	√	√	√	√	√	√	-				
	ASSYST Active Service System	√	√	√	√	-	√	-				
	ASSYST PLUS-PLUS Active Service System	√	√	√	√	-	√	-				
	SCM[MRM]-Steering column module	√	√	√	√	√	-	-				
	PTS-Parktronic system	√	√	√	√	√	-	-				
	AGW-Audio Gateway	√	√	√	√	√	-	-				
Information and communication	COMMAND/AUDIO-sound 50 or COMMAND	√	√	√	√	√	-	-				
	CDC-CD drive	√	√	√	√	-	-	-				

From 06/2005 to 05/2006

					HFS-hands-free system and microphone	√	√	√	-	-	-	-
					CTEL-car phone	√	√	√	√	√	-	-
					NAVI-navigation system (only with COMMAND combination of Japanese cars is invalid)	√	√	√	√	√	-	-
Seats and doors	DCM-FL-Door control module front left	√	√	√	√	√	√	-	-			
	DCM-FR-Door control module front right	√	√	√	√	√	√	-	-			
	DCM-RL-Door control module rear left	√	√	√	√	√	√	-	-			
	DCM-RR-Door control module rear right	√	√	√	√	√	√	-	-			
	TLC-Trunk lid control	√	√	√	√	√	-	-				
	ESA driver-Electric seat adjustment driver(with memory)	√	√	√	√	√	-	-				
	ESA passenger-Electric seat adjustment front passenger (with memory)	√	√	√	√	√	-	-				
	HS-Seat heater	√	√	√	-	-	-	-				
	DS-LF-Left front dynamic seat	√	√	√	√	√	-	-				
	DS-RF-Right front dynamic seat	√	√	√	√	√	-	-				
DSP-Pneumatic pump for dynamic seat	√	√	√	√	√	-	-					
Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning	√	√	√	√	√	-	-				
	HSW-Heated steering wheel	√	√	√	√	√	-	-				
	STH-Stationary heater with remote control	√	√	√	√	√	-	-				
Drive	Transmission	√	√	√	√	√	-	-				
	ESM-Electronic selector module	√	√	√	√	√	-	-				
	DTR-Distronic	√	√	√	√	-	-	-				
	ME-SFI-Motor electronics	√	√	√	√	-	√	-				
Chassis	SBC-Sensotronic Brake Control	√	√	√	√	-	√	-				
	ESP-Electronic stability program	√	√	√	√	√	√	-				
	Suspension	√	√	√	√	√	-	-				
	TPC-Tire pressure monitor	√	√	√	√	√	-	-				
Body	CGW-Central gateway	√	√	√	-	-	-	-				
	EZS-Electronic ignition switch/KG -Keyless Go(Special equipment)	√	√	√	√	√	-	-				
	AB-Airbag	√	√	√	√	-	√	-				
	WSS-Weight sensing system(USA)	√	√	√	√	-	-	-				
	Dr-side SAM-Driver signal acquisition and actuation module	√	√	√	√	√	-	-				
	Pass-side SAM-Passenger-side signal acquisition and actuation module	√	√	√	√	√	√	-				
	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	√	-	-				
	HRA-Headlamp range adjustment	√	√	√	√	√	-	-				
	OCP-Overhead control panel	√	√	√	√	√	√	-				
	UCP-Upper control panel	√	√	√	√	√	-	-				
	LCP-Lower control panel	√	√	√	√	√	-	-				
	RevETR-LF-Left front reversible emergency tensioning retractor	√	√	√	-	-	-	-				
	RevETR-RF-Right front reversible emergency tensioning retractor	√	√	√	-	-	-	-				
	On-board electrical system(voltage supply)	√	√	√	√	-	-	-				
	BCM-Battery control module	√	√	√	√	√	-	-				
AHE-Trailer recognition	√	√	√	√	√	-	-					
MSS-Special vehicle multifunton control module	√	√	√	-	-	-	-					
System diagnosis	√	√	√	-	-	-	-					
Information and communication	IC-Instrument cluster	√	√	√	√	√	√	-				
	ASSYST Active Service System	√	√	√	√	-	√	-				
	ASSYST PLUS-PLUS Active Service System	√	√	√	√	-	√	-				
	SCM[MRM]-Steering column module	√	√	√	√	√	-	-				
	PTS-Parktronic system	√	√	√	√	√	-	-				
	AGW-Audio Gateway	√	√	√	√	√	-	-				
	COMMAND/AUDIO-sound 50 or COMMAND	√	√	√	√	√	-	-				
	CDC-CD drive	√	√	√	√	-	-	-				
	HFS-hands-free system and microphone	√	√	√	-	-	-	-				
	CTEL-car phone	√	√	√	√	√	-	-				
NAVI-navigation system (only with COMMAND combination of Japanese cars is invalid)	√	√	√	√	√	-	-					

Benz

As of 06/2006

m

211



					ESA 'Front passenger' - Electric seat adjustment 'Front passenger'	√	√	√	√	-	-	-
					SIH-FOND-Rear passenger compartment seat heater	√	√	√	√	-	-	-
				Air conditioning	AAC-Air conditioning	√	√	√	√	√	-	-
Benz	Up to 08/2002	CL	215	Drive	Transmission	√	√	√	√	√	√	-
					ESM - Electronic selector module	√	√	√	√	√	√	-
					DTR - DISTRONIC	√	√	√	-	-	√	-
					ME2-SFI - Motor electronics	√	√	√	√	√	-	-
				Chassis	ESP - Electronic stability program	√	√	√	√	√	√	-
					Suspension	√	√	√	√	√	-	-
					TPC - Tire pressure monitor	√	√	√	√	√	-	-
				Body	AB - Airbag	√	√	√	√	-	√	-
					OCP - Overhead control panel	√	√	√	√	√	-	-
					EZS - Electronic ignition switch ELCODE(DAS 3)	√	√	√	√	-	√	-
					HRA - Headlamp range adjustment	√	√	√	√	√	-	-
					UCP - Upper control panel	√	√	√	√	√	-	-
					PSE - Pneumatic system equipment	√	√	√	√	√	-	-
					SAM-FL - Front left signal acquisition and actuation module	√	√	√	√	√	-	-
					SAM-FR - Front right signal acquisition and actuation module	√	√	√	√	√	-	-
					REAR SAM - Rear signal acquisition and actuation module	√	√	√	√	√	-	-
					AHE - Trailer recognition	√	√	√	√	√	-	-
					KG - Keyless Go	√	√	√	√	√	-	-
					MSS - Special vehicle multifunction control module	√	√	√	-	-	-	-
					Information and communication	ICM - Instrument cluster with maintenance interval display	√	√	√	√	√	√
				SCM [MRM] - Steering column module		√	√	√	√	√	-	-
				PTS - Parktronic system		√	√	√	√	√	-	-
				D2B - COMAND or AUDIO		√	√	√	√	√	-	-
				CDC - CD changer		√	√	√	-	-	-	-
				VCS - Voice control system		√	√	√	-	-	-	-
				SOUND - Sound system		√	√	√	-	-	-	-
				CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		√	√	√	-	-	-	-
				TV - TV tuner		√	√	√	-	-	-	-
				TELE AID, E-call or cellular telephone - Telematic system(K-wire)		√	√	√	√	√	-	-
				DN - Dynamic navigation by means of CTEL(K-wire)	√	√	√	-	-	-	-	
				Seats and doors	DCM-FL - Door control module front left	√	√	√	√	√	-	-
					DCM-FR - Door control module front right	√	√	√	√	√	-	-
					DCM-RL - Door control module rear left	√	√	√	√	√	-	-
					DCM-RR - Door control module rear right	√	√	√	√	√	-	-
					ESA-FL - Electric seat adjustment front left	√	√	√	√	√	-	-
					ESA-FR - Electric seat adjustment front right	√	√	√	√	√	-	-
					ESA-R - Electric seat adjustment rear	√	√	√	-	√	-	-
					OSB-FL - Multicontour backrest front left	√	√	√	√	√	-	-
					OSB-FR - Multicontour backrest front right	√	√	√	√	√	-	-
					OSB-R - Multicontour backrest rear	√	√	√	√	-	-	-
Air conditioning	AAC - Automatic air conditioning	√	√	√	√	√	√	-				
	REAR AC - Rear air conditioning	√	√	√	√	√	-	-				
	STH - Stationary heater	√	√	√	√	√	-	-				
	HSW - Heated steering wheel	√	√	√	-	-	-	-				
Drive	Transmission	√	√	√	√	√	√	-				
	ESM - Electronic selector module	√	√	√	√	√	-	-				
	DTR - DISTRONIC	√	√	√	-	-	-	-				
	ME-SFI 2.8 - Motor electronics 2.8	√	√	√	√	√	-	-				
Chassis	ESP - Electronic stability program	√	√	√	√	√	-	-				
	Suspension	√	√	√	√	√	-	-				
	TPC - Tire pressure monitor	√	√	√	√	√	-	-				
	AB - Airbag	√	√	√	√	-	√	-				
	CGW - Central gateway	√	√	√	-	-	-	-				
	RevETR-LF - Left front reversible emergency tensioning retractor	√	√	√	√	-	-	-				

Benz	As of 09/2002	CL	215	Body	RevETR-RF - Right front reversible emergency tensioning retractor	√	√	√	√	-	-	-
					OCP - Overhead control panel	√	√	√	√	√	-	-
					EZS - Electronic ignition switch ELCODE(DAS 3)	√	√	√	√	-	√	-
					HRA - Headlamp range adjustment	√	√	√	√	√	-	-
					HLCM-L - Left headlamp control module	√	√	√	√	√	-	-
					HLCM-R - Right headlamp control module	√	√	√	√	-	-	-
					UCP - Upper control panel	√	√	√	√	√	-	-
					PSE - Pneumatic system equipment	√	√	√	√	√	-	-
					SAM-FL - Front left signal acquisition and actuation module	√	√	√	√	√	-	-
					SAM-FR - Front right signal acquisition and actuation module	√	√	√	√	√	-	-
					REAR SAM - Rear signal acquisition and actuation module	√	√	√	√	√	-	-
					System diagnosis(only interior CAN fault)	√	√	√	√	-	-	-
					AHE - Trailer recognition	√	√	√	√	√	-	-
					KG - Keyless Go	√	√	√	√	√	-	-
					MSS - Special vehicle multifunction control module	√	√	√	-	-	-	-
				Information and communication	ICM - Instrument cluster with maintenance interval display	√	√	√	√	√	√	-
					SCM [MRM] - Steering column module	√	√	√	√	√	-	-
					PTS - Parktronic system	√	√	√	√	√	-	-
					AGW-Audio Gateway	√	√	√	√	-	-	-
					COMAND-display and operating unit	√	√	√	-	-	-	-
					CDC - CD changer	√	√	√	√	-	-	-
					HFS-hands-free system and microphone	√	√	√	-	√	-	-
					TV - TV tuner	√	√	√	√	-	-	-
					CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	√	√	√	√	-	-	-
					WAP communications services, e-mail,access to the Mercedes-Benz	√	√	√	-	-	-	-
					VCS - Voice control system	√	√	√	-	-	-	-
					SOUND - Sound system	√	√	√	-	-	-	-
					TELE AID, E-call or cellular telephone - Telematic system(k-wire)	√	√	√	√	√	-	-
				Seats and doors	DCM-FL - Door control module front left	√	√	√	√	√	-	-
					DCM-FR - Door control module front right	√	√	√	√	√	-	-
					DCM-RL - Door control module rear left	√	√	√	√	√	-	-
					DCM-RR - Door control module rear right	√	√	√	√	√	-	-
					ESA-FL - Electric seat adjustment front left	√	√	√	√	√	-	-
					ESA-FR - Electric seat adjustment front right	√	√	√	√	√	-	-
					ESA-R - Electric seat adjustment rear	√	√	√	-	√	-	-
					OSB-FL - Multicontour backrest front left	√	√	√	√	√	-	-
					OSB-FR - Multicontour backrest front right	√	√	√	√	√	-	-
				Air conditioning	OSB-R - Multicontour backrest rear	√	√	√	√	-	-	-
					AAC - Automatic air conditioning	√	√	√	√	√	-	-
					REAR AC - Rear air conditioning	√	√	√	√	√	-	-
					STH - Stationary heater	√	√	√	√	√	-	-
				Drive	HSW - Heated steering wheel	√	√	√	-	-	-	-
					ETC-Electronic transmission	√	√	√	√	√	√	-
ISM-Intelligent servo module	√	√	√		√	-	-	-				
ME6/8-Engine system	√	√	√		√	√	√	-				
DTR-DISTRONIC	√	√	√		√	-	-	-				
SGR-Radar ranging system	√	√	√		√	√	-	-				
Chassis	ABR-Adaptive brake	√	√		√	√	-	√	-			
	EPB-Electric parking brake	√	√		√	√	√	√	-			
	TPC-Tyre inflation pressure monitoring	√	√		√	√	√	-	-			
	AM-Suspension system	√	√		√	√	√	√	-			
	SRS-Airbag	√	√	√	√	-	√	-				
	WSS-Weight sensor system	√	√	√	-	-	-	-				
	RevETR-LF-Left front convertible seat belt tensioner	√	√	√	√	-	-	-				
	RevETR-LR-Right front convertible seat belt tensioner	√	√	√	√	-	-	-				
	CGW-Central gateway	√	√	√	-	-	-	-				
	EIS-Electronic ignition starting switch	√	√	√	√	-	-	-				
	KG-keyless start	√	√	√	√	√	-	-				

Benz	-	C	216	Body	XALWA-L-Left side xenon headlight	√	√	√	√	√	-	-
					XALWA-R-Right side xenon headlight	√	√	√	√	√	-	-
					OCP-Roof operation unit	√	√	√	√	√	-	-
					UCP-Upper operation area	√	√	√	√	√	-	-
					SAM-Driver signal detection and control module	√	√	√	√	√	√	-
					REAR-SAM-Rear signal acquisition and execution module	√	√	√	√	-	-	-
					System-System diagnosis	√	√	√	-	-	-	-
					BNS-On-board power grid control unit	√	√	√	√	√	-	-
				Information and communication	NSA-Night View Assist	√	√	√	√	√	-	-
					IC-Instrument cluster	√	√	√	√	√	√	-
					ASSYST-Active maintenance system	√	√	√	√	-	√	-
					ASSYSTPLUS	√	√	√	√	-	√	-
					SCM-Steering module	√	√	√	√	√	-	-
					PFK-Reversing camera	√	√	√	√	-	-	-
					PTS-PARKTRONIC	√	√	√	√	√	√	-
					COMAND with integrated electronic communication system gateway	√	√	√	√	√	√	-
					TUNER-radio tuner with power amplifier	√	√	√	-	-	-	-
					CTEL-mobile phone adapter connector with universal connector	√	√	√	√	√	-	-
					VCS-voice control	√	√	√	√	√	-	-
					TV-TV tuner	√	√	√	√	-	-	-
					SDAR-Satellite Radio	√	√	√	√	√	-	-
					ZAN-Central display	√	√	√	-	-	-	-
					COU-Central operation unit	√	√	√	√	√	-	-
					KBE-H-Rear AC control unit	√	√	√	-	-	-	-
				Seat and door	TSG-VL-Left front door control unit	√	√	√	√	√	-	-
					DCM-FR-Right front door control module	√	√	√	√	√	-	-
					DCM-RL-Left Rear door control unit	√	√	√	√	√	-	-
					DCM-RR-Right Rear door control unit	√	√	√	√	√	-	-
					ESA-FL-Left front electric seat adjustment	√	√	√	√	√	-	-
					ESA-FR-Right front electric seat adjustment	√	√	√	√	√	-	-
					ESA-R-Rear electric seat adjustment	√	√	√	√	√	-	-
					DS-LF-Left front dynamic driving seat	√	√	√	√	-	-	-
					DS-RF-Right front dynamic driving seat	√	√	√	√	-	-	-
					DSP-Dynamic driving seat pneumatic pump	√	√	√	√	-	-	-
				TLC-Trunk lid controller	√	√	√	√	√	-	-	
				Air conditioner	AAC-Automatic air conditioner	√	√	√	√	√	√	-
					KBE-H-RearAir conditioner operation unit	√	√	√	-	-	-	-
				Drive	ME 9.7-Motor electronics 9.7	√	√	√	√	√	-	-
					Transmission	√	√	√	√	-	√	-
					DTR-Distronic	√	√	√	-	-	-	-
					ESM-Electronic selector module	√	√	√	√	√	-	-
				Chassis	SBC-Sensotronic Brake Control	√	√	√	√	-	√	-
					ESP-Electronic stability program	√	√	√	√	√	√	-
					AIRmatic	√	√	√	√	√	-	-
					TPC-Tire pressure monitor	√	√	√	√	√	-	-
				Body	CGW-Central gateway	√	√	√	√	-	-	-
					EZS-Electronic ignition switch	√	√	√	√	√	√	-
					AB-Airbag	√	√	√	√	-	√	-
					WSS-Weight sensing system	√	√	√	-	-	-	-
					System diagnosis(CAN)	√	√	√	-	-	-	-
					Dr-side SAM-Driver signal acquisition and actuation module	√	√	√	√	√	-	-
					Pass-side SAM-Passenger-side signal acquisition and actuation module	√	√	√	√	√	-	-
REAR SAM-Rear signal acquisition and actuation module	√	√	√		√	√	-	-				
LCP-Lower control panel	√	√	√		√	√	-	-				
UCP-Upper control panel	√	√	√		√	√	-	-				
OCP-Overhead control panel	√	√	√		√	√	-	-				
RevETR-LF-Left front reversible emergency tensioning retractor	√	√	√		√	-	-	-				
RevETR-RF-Right front reversible emergency tensioning retractor	√	√	√	√	-	-	-					
HRA-Automatic headlamp range adjustment and headlamp control	√	√	√	√	√	-	-					

Benz	-	CLS	219	Information and communication	PTS-Parktronic system	√	√	√	√	√	-	-
					SCM[MRM]-Steering column module	√	√	√	√	√	-	-
IC-Instrument cluster	√	√	√		√	√	√	-				
ASSYST-Active Service System	√	√	√		√	-	-	-				
ASSYST PLUS-PLUS Active Service System	√	√	√		√	-	√	-				
TELE AID-Telematic services Emergency call	√	√	√		-	-	-	-				
TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	√	√	√		-	-	-	-				
TELE AID-Telematic services Stolen vehicle tracking	√	√	√		-	-	-	-				
TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√		-	-	-	-				
DAB-Digital radio	√	√	√		√	-	-	-				
SDAR-Satellite radio(Valid for USA)	√	√	√		√	-	-	-				
Seats and doors	ESA driver-Electric seat adjustment driver(with memory)	√	√	√	√	√	-	-				
	ESA passenger-Electric seat adjustment passenger	√	√	√	√	√	-	-				
	HS-Seat heater	√	√	√	√	√	-	-				
	DCM-FL-Door control module front left	√	√	√	√	√	-	-				
	DCM-FR-Door control module front right	√	√	√	√	√	-	-				
	DCM-RL-Door control module rear left	√	√	√	√	√	-	-				
Air conditioning	DCM-RR-Door control module rear right	√	√	√	√	√	-	-				
	AAC-Automatic air conditioning	√	√	√	√	√	-	-				
	HSW-Heated steering wheel	√	√	√	-	√	-	-				
218	Drive	STH-Stationary heater	√	√	√	√	-	-	-			
		ISM-Shift module(A80)	√	√	√	√	-	-	-			
		FSCU-Fuel pump	√	√	√	-	-	-	-			
		ME2-SFI-Motor electronics 2	√	√	√	√	√	√	-			
		SGR-Radar sensors control unit	√	√	√	√	-	-	-			
		SCR-Selective Catalytic Reduction	√	√	√	-	-	-	-			
		ESM-Electronic selector module	√	√	√	√	√	-	-			
	Body	ETC-Electronic transmission control	√	√	√	√	√	√	-			
		CGW[ZGW]-Central gateway	√	√	√	√	-	-	-			
		EZS-Electronic ignition lock	√	√	√	√	-	√	-			
		KG-Keyless Go	√	√	√	√	√	-	-			
		WSS-Weight sensing system	√	√	√	√	-	-	-			
		SRS-Supplemental restraint system	√	√	√	√	-	-	-			
		RevETR-LF-Left front reversible emergency tensioning retractor	√	√	√	√	-	-	-			
		RevETR-RF-Right front reversible emergency tensioning retractor	√	√	√	√	-	-	-			
		Driver-side SAM-Driver signal acquisition and actuation module	√	√	√	√	√	-	-			
	Information and communication	Rear SAM-Rear signal acquisition and actuation module	√	√	√	√	√	-	-			
Trailer recognition module		√	√	√	-	-	-	-				
COU[ZBE]-Central operating unit		√	√	√	√	√	-	-				
DAB-Digital radio		√	√	√	√	-	-	-				
ZAN-Central display		√	√	√	√	-	-	-				
Left rear screen		√	√	√	√	-	-	-				
Right rear screen		√	√	√	√	-	-	-				
RFK-Backup camera		√	√	√	√	-	-	-				
COMAND or AUDIO		√	√	√	√	√	√	-				
ICM-Instrument cluster with maintenance interval display		√	√	√	√	-	√	√				
Information and communication	MFK-Multifunction camera	√	√	√	√	-	-	-				
	NSA-Night View Assist	√	√	√	√	√	-	-				
	SCCM-Steering column module(N80)	√	√	√	√	√	-	-				
	SDAR-Satellite radio(Valid for USA)	√	√	√	√	-	-	-				
	SOUND-Sound system	√	√	√	-	-	-	-				
	CTEL-Cellular telephone(JAPAN)	√	√	√	√	-	-	-				
	TV-TV tuner(AGW)	√	√	√	√	-	-	-				
	UCI	√	√	√	-	-	-	-				
	TELE AID-Control unit	√	√	√	-	-	-	-				
TELE AID-Telematic services Emergency call	√	√	√	-	-	-	-					

Benz

2010年之后

CLS



Benz	Up to 08/2002	S	220		TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	-	-	-	-
					TELE AID-Telematic services MB Info,Roadside assistance(USA,Canada),Tele diagnosis(ECE)	√	√	√	-	-	-	-
					TELE AID-Telematic services Stolen vehicle tracking	√	√	√	-	-	-	-
				Seats and doors	DCU-LF-Left front door	√	√	√	√	-	-	-
					DCU-RF-Right front door	√	√	√	√	-	-	-
					DCU-LR-Left rear door	√	√	√	√	√	-	-
					DCU-RR-Right rear door	√	√	√	√	√	-	-
					SIH-FOND-Rear passenger compartment seat heater	√	√	√	√	-	-	-
					DSP-Pneumatic pump for dynamic seat	√	√	√	√	-	-	-
					HKS-Tailgate control	√	√	√	√	√	-	-
					ESA driver	√	√	√	√	√	-	-
				Air conditioning	ESA passenger	√	√	√	√	-	-	-
					AAC-Air conditioning	√	√	√	√	√	-	-
					Stationary heater	√	√	√	√	-	-	-
				Drive	Transmission	√	√	√	√	√	√	-
					ESM - Electronic selector module	√	√	√	√	√	√	-
					DTR - Distronic	√	√	√	-	-	√	-
					ME2-SFI - Motor electronics	√	√	√	√	√	-	-
				Chassis	ESP - Electronic stability program	√	√	√	√	√	√	-
					Suspension	√	√	√	√	√	-	-
					TPC - Tire pressure monitor	√	√	√	√	√	-	-
				Body	AB - Airbag	√	√	√	√	-	√	-
					OCP - Overhead control panel	√	√	√	√	√	-	-
					EZS - Electronic ignition switch ELCODE(DAS 3)	√	√	√	√	-	√	-
					HRA - Headlamp range adjustment	√	√	√	√	√	-	-
					UCP - Upper control panel	√	√	√	√	√	-	-
					PSE - Pneumatic system equipment	√	√	√	√	√	-	-
SAM-FL - Front left signal acquisition and actuation module	√	√	√		√	√	-	-				
SAM-FR - Front right signal acquisition and actuation module	√	√	√		√	√	-	-				
REAR SAM - Rear signal acquisition and actuation module	√	√	√		√	√	-	-				
AHE - Trailer recognition	√	√	√		√	√	-	-				
KG - Keyless Go	√	√	√		√	√	-	-				
MSS - Special vehicle multifunction control module	√	√	√	-	-	-	-					
Information and communication	ICM - Instrument cluster with maintenance interval display	√	√	√	√	√	√	-				
	SCM [MRM] - Steering column module	√	√	√	√	√	-	-				
	PTS - Parktronic system	√	√	√	√	√	-	-				
	D2B - COMAND or AUDIO	√	√	√	√	√	-	-				
	CDC - CD changer	√	√	√	-	-	-	-				
	VCS - Voice control system	√	√	√	-	-	-	-				
	SOUND - Sound system	√	√	√	-	-	-	-				
	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	√	√	√	-	-	-	-				
	TV - TV tuner	√	√	√	-	-	-	-				
	TELE AID, E-call or cellular telephone - Telematic system(K-wire)	√	√	√	√	√	-	-				
	DN - Dynamic navigation by means of CTEL(K-wire)	√	√	√	-	-	-	-				
Seats and doors	DCM-FL - Door control module front left	√	√	√	√	√	-	-				
	DCM-FR - Door control module front right	√	√	√	√	√	-	-				
	DCM-RL - Door control module rear left	√	√	√	√	√	-	-				
	DCM-RR - Door control module rear right	√	√	√	√	√	-	-				
	ESA-FL - Electric seat adjustment front left	√	√	√	√	√	-	-				
	ESA-FR - Electric seat adjustment front right	√	√	√	√	√	-	-				
	ESA-R - Electric seat adjustment rear	√	√	√	-	√	-	-				
	OSB-FL - Multicontour backrest front left	√	√	√	√	√	-	-				
OSB-FR - Multicontour backrest front right	√	√	√	√	√	-	-					
OSB-R - Multicontour backrest rear	√	√	√	√	-	-	-					

					Air conditioning	AAC - Automatic air conditioning	√	√	√	√	√	√	-	
						REAR AC - Rear air conditioning	√	√	√	√	√	-	-	
						STH - Stationary heater	√	√	√	√	√	-	-	
						HSW - Heated steering wheel	√	√	√	-	-	-	-	
					Drive	Transmission	√	√	√	√	√	√	-	
						ESM - Electronic selector module	√	√	√	√	√	-	-	
						DTR - Distronic	√	√	√	-	-	-	-	
						ME-SFI 2.8 - Motor electronics 2.8	√	√	√	√	√	-	-	
					Chassis	ESP - Electronic stability program	√	√	√	√	√	-	-	
						Suspension	√	√	√	√	√	-	-	
						TPC - Tire pressure monitor	√	√	√	√	√	-	-	
					Body	AB - Airbag	√	√	√	√	-	√	-	
						CGW - Central gateway	√	√	√	-	-	-	-	-
						RevETR-LF - Left front reversible emergency tensioning retractor	√	√	√	√	-	-	-	-
						RevETR-RF - Right front reversible emergency tensioning retractor	√	√	√	√	-	-	-	-
						OCP - Overhead control panel	√	√	√	√	√	-	-	-
						EZS - Electronic ignition switch ELCODE(DAS 3)	√	√	√	√	-	√	-	-
						HRA - Headlamp range adjustment	√	√	√	√	√	-	-	-
						HLCM-L - Left headlamp control module	√	√	√	√	√	-	-	-
						HLCM-R - Right headlamp control module	√	√	√	√	-	-	-	-
						UCP - Upper control panel	√	√	√	√	√	-	-	-
						PSE - Pneumatic system equipment	√	√	√	√	√	-	-	-
						SAM-FL - Front left signal acquisition and actuation module	√	√	√	√	√	-	-	-
						SAM-FR - Front right signal acquisition and actuation module	√	√	√	√	√	-	-	-
						REAR SAM - Rear signal acquisition and actuation module	√	√	√	√	√	-	-	-
						System diagnosis(only interior CAN fault)	√	√	√	√	-	-	-	-
						AHE - Trailer recognition	√	√	√	√	√	-	-	-
						KG - Keyless Go	√	√	√	√	√	-	-	-
					MSS - Special vehicle multifunction control module	√	√	√	-	-	-	-	-	
					Information and communication	ICM - Instrument cluster with maintenance interval display	√	√	√	√	√	√	-	
						SCM [MRM] - Steering column module	√	√	√	√	√	-	-	
						PTS - Parktronic system	√	√	√	√	√	-	-	
						AGW-Audio Gateway	√	√	√	√	-	-	-	
						COMAND-display and operating unit	√	√	√	-	-	-	-	
						CDC - CD changer	√	√	√	√	-	-	-	
						HFS-hands-free system and microphone	√	√	√	-	√	-	-	
						TV - TV tuner	√	√	√	√	-	-	-	
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	√	√	√	√	-	-	-	
						WAP communications services, e-mail,access to the Mercedes-Benz	√	√	√	-	-	-	-	
						VCS - Voice control system	√	√	√	-	-	-	-	
					SOUND - Sound system	√	√	√	-	-	-	-		
					TELE AID, E-call or cellular telephone - Telematic system(k-wire)	√	√	√	√	√	-	-		
					Seats and doors	DCM-FL - Door control module front left	√	√	√	√	√	-	-	
						DCM-FR - Door control module front right	√	√	√	√	√	-	-	
						DCM-RL - Door control module rear left	√	√	√	√	√	-	-	
						DCM-RR - Door control module rear right	√	√	√	√	√	-	-	
						ESA-FL - Electric seat adjustment front left	√	√	√	√	√	-	-	
						ESA-FR - Electric seat adjustment front right	√	√	√	√	√	-	-	
						ESA-R - Electric seat adjustment rear	√	√	√	-	√	-	-	
						OSB-FL - Multicontour backrest front left	√	√	√	√	√	-	-	
						OSB-FR - Multicontour backrest front right	√	√	√	√	√	-	-	
					OSB-R - Multicontour backrest rear	√	√	√	√	-	-	-		
					Air conditioning	AAC - Automatic air conditioning	√	√	√	√	√	-	-	
						REAR AC - Rear air conditioning	√	√	√	√	√	-	-	
						STH - Stationary heater	√	√	√	√	√	-	-	
						HSW - Heated steering wheel	√	√	√	-	-	-	-	
					Drive	ETC-Electronic transmission	√	√	√	√	√	√	-	
						ISM-Intelligent servo module	√	√	√	√	-	-	-	
						ME6/8-Engine system	√	√	√	√	√	√	-	

Benz

As of 09/2002

S

220

Benz	-	S	221		DTR-DISTRONIC	√	√	√	√	-	-	-
					SGR-Radar ranging system	√	√	√	√	√	-	-
				Chassis	ABR-Adaptive brake	√	√	√	√	-	√	-
					EPB-Electric parking brake	√	√	√	√	√	√	-
					TPC-Tyre inflation pressure monitoring	√	√	√	√	√	-	-
					AM-Suspension system	√	√	√	√	√	√	-
					SRS-Airbag	√	√	√	√	-	√	-
				Body	WSS-Weight sensor system	√	√	√	-	-	-	-
					RevETR-LF-Left front convertible seat belt tensioner	√	√	√	√	-	-	-
					RevETR-LR-Right front convertible seat belt tensioner	√	√	√	√	-	-	-
					CGW-Central gateway	√	√	√	-	-	-	-
					EIS-Electronic ignition starting switch	√	√	√	√	-	-	-
					KG-keyless start	√	√	√	√	√	-	-
					XALWA-L-Left side xenon headlight	√	√	√	√	√	-	-
					XALWA-R-Right side xenon headlight	√	√	√	√	√	-	-
					OCP-Roof operation unit	√	√	√	√	√	-	-
					UCP-Upper operation area	√	√	√	√	√	-	-
					SAM-Driver signal detection and control module	√	√	√	√	√	√	-
					REAR-SAM-Rear signal acquisition and execution module	√	√	√	√	-	-	-
					System-System diagnosis	√	√	√	-	-	-	-
					BNS-On-board power grid control unit	√	√	√	√	√	-	-
					Information and communication	NSA-Night View Assist	√	√	√	√	√	-
				IC-Instrument cluster		√	√	√	√	√	√	-
				ASSYST-Active maintenance system		√	√	√	√	-	√	-
				ASSYSTPLUS		√	√	√	√	-	√	-
				SCM-Steering module		√	√	√	√	√	-	-
				PFK-Reversing camera		√	√	√	√	-	-	-
				PTS-PARKTRONIC		√	√	√	√	√	√	-
				COMAND with integrated electronic communication system gateway		√	√	√	√	√	√	-
				TUNER-radio tuner with power amplifier		√	√	√	-	-	-	-
				CTEL-mobile phone adapter connector with universal connector		√	√	√	√	√	-	-
				VCS-voice control		√	√	√	√	√	-	-
				TV-TV tuner		√	√	√	√	-	-	-
				SDAR-Satellite Radio		√	√	√	√	√	-	-
				ZAN-Central display		√	√	√	-	-	-	-
				COU-Central operation unit		√	√	√	√	√	-	-
				Seat and door	KBE-H-Rear AC control unit	√	√	√	-	-	-	-
					TSG-VL-Left front door control unit	√	√	√	√	√	-	-
					DCM-FR-Right front door control module	√	√	√	√	√	-	-
					DCM-RL-Left Rear door control unit	√	√	√	√	√	-	-
					DCM-RR-Right Rear door control unit	√	√	√	√	√	-	-
					ESA-FL-Left front electric seat adjustment	√	√	√	√	√	-	-
					ESA-FR-Right front electric seat adjustment	√	√	√	√	√	-	-
					ESA-R-Rear electric seat adjustment	√	√	√	√	√	-	-
					DS-LF-Left front dynamic driving seat	√	√	√	√	-	-	-
					DS-RF-Right front dynamic driving seat	√	√	√	√	-	-	-
				Air conditioner	DSP-Dynamic driving seat pneumatic pump	√	√	√	√	-	-	-
					TLC-Trunk lid controller	√	√	√	√	√	-	-
					AAC-Automatic air conditioner	√	√	√	√	√	√	-
					KBE-H-RearAir conditioner operation unit	√	√	√	-	-	-	-
				Drive	Transmission	√	√	√	√	√	√	-
					ESM - Electronic selector module	√	√	√	√	√	-	-
ME-SFI 2.8 - Motor electronics 2.8	√	√	√		√	-	-	-				
Chassis	SBC - Sensotronic Brake Control	√	√	√	√	-	-	-				
	ESP - Electronic stability program	√	√	√	√	√	√	-				
	ABC - ABC active body control	√	√	√	√	√	-	-				
	TPC - Tire pressure monitor	√	√	√	√	√	-	-				
	AB - Airbag	√	√	√	√	-	√	-				
	BNS - Vehicle power supply control module	√	√	√	√	-	-	-				
	OCP - Overhead control panel	√	√	√	√	√	-	-				
	EZS - Electronic ignition switch	√	√	√	√	-	√	-				
	HRA-FR - Front right headlamp range control	√	√	√	√	√	-	-				

Benz	-	SL	230	Body	HRA-FL - Front left headlamp range control	√	√	√	√	-	-	-
					LCP - Lower control panel	√	√	√	√	√	-	-
					PSE - Pneumatic system equipment	√	√	√	-	√	-	-
					Dr-side SAM - Driver signal acquisition and actuation module	√	√	√	√	√	-	-
					Pass-side SAM - Passenger-side signal acquisition and actuation module	√	√	√	√	√	-	-
					REAR SAM - Rear signal acquisition and actuation module	√	√	√	√	√	-	-
					RVC - Rollover bar/vario roof control module	√	√	√	√	-	-	-
					KG - Keyless Go	√	√	√	√	√	-	-
					System diagnosis	√	√	√	-	-	-	-
				Information and communication	ICM - Instrument cluster with maintenance interval display	√	√	√	√	√	√	-
					SCM [MRM] - Steering column module	√	√	√	√	-	-	-
					PTS - Parktronic system	√	√	√	√	-	-	-
					D2B - COMAND or AUDIO	√	√	√	√	√	-	-
					CDC - CD changer	√	√	√	-	-	-	-
					VCS - Voice control system	√	√	√	-	-	-	-
					SOUND - Sound system	√	√	√	-	-	-	-
					CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	√	√	√	-	-	-	-
					TELE AID - Telematic system(K-wire)	√	√	√	√	√	-	-
				TV - TV tuner(Not valid for J)	√	√	√	-	-	-	-	
				Seats and doors	DCM-L - Door control module left	√	√	√	√	-	-	-
					DCM-R - Door control module right	√	√	√	√	-	-	-
					ESA-FL - Electric seat adjustment front left	√	√	√	√	√	-	-
					ESA-FR - Electric seat adjustment front right	√	√	√	√	√	-	-
					OSB-FL - Multicontour backrest front left	√	√	√	√	-	-	-
					OSB-FR - Multicontour backrest front right	√	√	√	√	-	-	-
				Air conditioning	AAC - Automatic air conditioning	√	√	√	√	-	-	-
					STH - Stationary heater with remote control	√	√	√	√	√	-	-
					HSW - Heated steering wheel	√	√	√	-	-	-	-
				Drive	Transmission	√	√	√	√	√	√	-
					ESM - Electronic selector module	√	√	√	√	√	-	-
DTR - Distronic	√	√	√		-	-	√	-				
Chassis	ME-SFI 2.7.1 - Motor electronics 2.7.1	√	√	√	√	√	-	-				
	SBC - Left Sensotronic Brake Control	√	√	√	√	-	-	-				
	SBC - Right Sensotronic Brake Control	√	√	√	√	-	-	-				
	ESP - Electronic stability program	√	√	√	√	√	√	-				
	AIRmatic - AIRmatic	√	√	√	√	√	√	-				
	TPC - Tire pressure monitor	√	√	√	√	-	√	-				
Body	AB - Airbag	√	√	√	√	-	√	-				
	BNS - Vehicle power supply control module	√	√	√	-	-	-	-				
	CGW - Central gateway	√	√	√	-	-	-	-				
	EZS-Electronic ignition switch/KG -Keyless Go(Special equipment)	√	√	√	√	-	√	-				
	HRA - Automatic headlamp range adjustment and headlamp control	√	√	√	√	√	√	-				
	OCP - Overhead control panel	√	√	√	√	√	-	-				
	VPF (Front control panel) - Front control panel	√	√	√	√	√	-	-				
	HBF (Rear control panel) - Rear control field	√	√	√	√	√	-	-				
	Dr-side SAM - Driver signal acquisition and actuation module	√	√	√	√	√	-	-				
	Pass-side SAM - Passenger-side signal acquisition and actuation module	√	√	√	√	√	-	-				
	Rear SAM 1 - Rear signal acquisition and actuation module 1	√	√	√	√	√	-	-				
	Rear SAM 2 - Rear signal acquisition and actuation module 2	√	√	√	√	√	-	-				
	System diagnosis (only interior CAN fault)	√	√	√	√	-	-	-				
MSS - Special vehicle multifunction control module	√	√	√	-	√	-	-					
Maybach	ICM - Instrument cluster	√	√	√	√	√	√	-				
	SCM [MRM] - Steering column module	√	√	√	√	√	√	-				
	PTS - Parktronic system	√	√	√	√	√	-	-				

				Information and communication	AGW-Audio Gateway	√	√	√	√	-	-	-				
					COMAND-Sound	√	√	√	-	-	-	-				
					CDC-CD drive	√	√	√	√	-	-	-				
					CTEL-portable telephone adapter interface	√	√	√	√	-	-	-				
					NAVI-navigation system	√	√	√	-	-	-	-				
					VCS-voice control	√	√	√	-	-	-	-				
					TV-TV tuner	√	√	√	-	-	-	-				
					Audio-Audio System	√	√	√	-	-	-	-				
					TELE-Communication system	√	√	√	-	-	-	-				
				Seats and doors	DCM-FL - Door control module front left	√	√	√	√	√	-	-				
					DCM-FR - Door control module front right	√	√	√	√	√	-	-				
					DCM-RL - Door control module rear left	√	√	√	√	√	-	-				
					DCM-RR - Door control module rear right	√	√	√	√	√	-	-				
					PWC-partition control module	√	√	√	√	√	-	-				
					ESA-FL - Electric seat adjustment front left	√	√	√	√	√	-	-				
					ESA-FR - Electric seat adjustment front right	√	√	√	√	√	-	-				
					ESA-LR - Left rear electrical seat adjustment	√	√	√	√	√	-	-				
					ESA-RR - Right rear electrical seat adjustment	√	√	√	√	√	-	-				
				TLC - Trunk lid control	√	√	√	√	√	-	-					
				Air conditioning	AAC - Automatic air conditioning	√	√	√	√	√	-	-				
					STH - Stationary heater	√	√	√	√	-	-	-				
HSW - Heated steering wheel	√	√	√		√	√	√	-								
Benz	-	α	245	Drive	ESM - Electronic selector module	√	√	√	√	√	-	-				
					FCVT - Continuously variable automatic transmission	√	√	√	√	-	√	-				
					ME-SFI - Motor electronics	√	√	√	√	√	-	-				
				Chassis	ESP - Electronic stability program	√	√	√	√	-	√	-				
					ES - Electrical power steering	√	√	√	√	-	-	-				
				Body	AB - Airbag	√	√	√	√	-	√	-				
					EZS - Electronic ignition switch ( Without Keyless Go )	√	√	√	√	-	√	-				
					OCP - Overhead control panel	√	√	√	√	√	-	-				
				Information and communication	SAM - Signal acquisition and actuation module	√	√	√	√	√	-	-				
					IC - Instrument cluster with maintenance interval display	√	√	√	√	√	√	-				
					SCM [MRM] - Steering column module	√	√	√	√	√	-	-				
				Seats and doors	PTS - Parktronic system	√	√	√	√	-	-	-				
					DCM-FL - Door control module front left	√	√	√	√	√	-	-				
					DCM-FR - Door control module front right	√	√	√	√	√	-	-				
					DCM-RL - Door control module rear left	√	√	√	√	√	-	-				
				Air conditioning	DCM-RR - Door control module rear right	√	√	√	√	√	-	-				
					C-ACC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	√	√	-	-				
				Benz	-	α	251	Drive	Transmission	√	√	√	√	-	√	-
									ISM-Intelligent Servo Module	√	√	√	√	-	-	-
									FSCU-Control unit'Fuel pump'	√	√	√	√	-	-	-
									ME9.7-Motor electronics 9.7	√	√	√	√	√	-	-
Chassis	ENR electronic level control	√	√					√	√	√	-	-				
	ESP-Electronic stability program	√	√					√	√	√	√	-				
	TPC-Tire Pressure Monitor	√	√					√	√	-	-	-				
Body	EHPS-Electrical power steering	√	√					√	√	-	-	-				
	AB-Airbag	√	√					√	√	-	√	-				
	WSS-Weight sensing system	√	√					√	√	-	-	-				
	EZS-Electronic ignition switch	√	√					√	√	-	√	-				
	CGW-Central Gateway	√	√					√	-	-	-	-				
	Keyless Go	√	√					√	√	√	-	-				
	OCP-Overhead Control Panel	√	√					√	√	√	-	-				
	UCP-Upper control panel	√	√					√	√	-	-	-				
	HBF(Rear contrl panel)-Rear control field	√	√					√	√	√	-	-				
	SAM-F-Signal acquisition and actuation module front	√	√					√	√	√	-	-				
READ SAM-Rear signal acquisition and actuation module	√	√	√					√	√	-	-					
Information and communication	System diagnostics(only interior CAN fault)	√	√					√	-	-	-	-				
	IC-Instrument	√	√					√	√	√	√	-				
ASSYST Active Service System	√	√	√					√	-	√	-					



					ERA - Electric fold-down backrest system (3rd seat row)	√	√	√	√	√	-	-
					HS - Seat heater	√	√	√	√	√	-	-
				Air conditioning	AAC - Automatic air conditioning	√	√	√	√	√	-	-
					STH - Stationary heater with remote control	√	√	√	√	-	-	-
					HSW - Heated steering wheel	√	√	√	-	-	-	-
				Drive	ME 9.7-9.7 engine systems (CAN bus chassis)	√	√	√	√	√	√	-
					FSCU-fuel pump (power CAN bus)	√	√	√	√	-	-	-
					ETC-Electronic Transmission (Power CAN bus)	√	√	√	√	√	√	-
					ESM-electronic gear selector module (power CAN bus)	√	√	√	√	√	-	-
				Chassis	ABR-adaptive brake (CAN bus chassis)	√	√	√	√	-	√	-
					TPC-tire pressure monitoring system (internal CAN bus)	√	√	√	√	-	-	-
				Body	CGW-central gateway (central CAN bus)	√	√	√	√	-	-	-
					EZS-electronic ignition starter switch (Interior space CAN bus)	√	√	√	√	-	√	-
					KG-keyless start (Interior space CAN bus)	√	√	√	-	-	-	-
					XALWA-L-left xenon headlights (front area CAN bus)	√	√	√	√	√	-	-
					XALWA-R-right xenon headlights (front area CAN bus)	√	√	√	√	√	-	-
					Airbag AB-(CAN bus chassis)	√	√	√	√	-	-	-
					Dr-side SAM-Driver Signal detection and control module (Interior space CAN bus)	√	√	√	√	√	-	-
					REAR SAM-Back seat area inter-nal Signal detection and control module (Interior space CAN bus)	√	√	√	√	√	-	-
					OCP-top control panel (internal CAN bus)	√	√	√	√	√	√	-
					COU [ZBE] - central operating unit	√	√	√	√	√	-	-
					WBS-Hazard warning switch	√	√	√	√	-	-	-
					WSS - Weight sensing system (USA) (Interior CAN bus)	√	√	√	√	-	-	-
					RevETR-LF-Left front convertible, seat belt tensioner (chassis CAN bus)	√	√	√	√	-	-	-
					RevETR-RF-Right front convertible, seat belt tensioner (chassis CAN bus)	√	√	√	√	-	-	-
				Information and communication	ICM-dashboard with maintenance setting(internal CAN bus)	√	√	√	√	√	√	-
					SCM [MRM] - steering column module (chassis CAN bus)	√	√	√	√	√	-	-
					PTS-Parktronic system (Interior space CAN bus)	√	√	√	√	√	-	-
					COMMAND-with integrated electronic communications gate-way COMMAND (MOST network management and diagnostics)	√	√	√	√	√	√	-
					CTEL-mobile phone adapter with universal connector	√	√	√	√	√	-	-
					TV-tuner(does not apply to Japan and the US)	√	√	√	√	-	-	-
					SDAR-Satellite Radio(USA)	√	√	√	√	√	-	-
					ZAN-central display	√	√	√	√	-	-	-
				Seats and doors	DCM-FL-Left front door control unit (Interior space CAN bus)	√	√	√	√	√	-	-
					DCM-FR-Right front door control unit (Interior space CAN bus)	√	√	√	√	√	-	-
					DCM-RL-Left rear door control unit (internal CAN bus)	√	√	√	√	√	-	-
					DCM-RR-Right rear door control unit (internal CAN bus)	√	√	√	√	√	-	-
					ESA driver-driver's seat adjustment (internal CAN bus)	√	√	√	√	√	-	-
				Air conditioning	AAC-automatic air conditioning (vehicle interior space CAN bus)	√	√	√	√	√	-	-
				Drive	ME-SFI 2.8 - Motor electronics 2.8	√	√	√	√	-	-	-
					ETC - Electronic transmission control	√	√	√	√	-	-	-
					ESM - Electronic selector module	√	√	√	√	√	-	-
					AB - Airbag	√	√	√	√	-	-	-
					EZS - Electronic ignition switch	√	√	√	√	-	-	-

Benz	-	GLK	463	Body	UCP - Upper control panel	√	√	√	√	√	-	-
					SAM-F - Signal acquisition and actuation module front	√	√	√	√	√	-	-
					REAR SAM - Rear signal acquisition and actuation module	√	√	√	√	√	-	-
					AHE - Trailer recognition	√	√	√	√	√	-	-
					OCP - Overhead control panel	√	√	√	√	√	-	-
					MSS - Special vehicle multifunction control module	√	√	√	√	-	-	-
				Information and communication	ICM - Instrument cluster with maintenance interval display	√	√	√	√	√	-	-
					D2B - COMAND or AUDIO	√	√	√	√	-	-	-
				Seats and doors	DCM-FL - Door control module front left	√	√	√	√	√	-	-
					DCM-FR - Door control module front right	√	√	√	√	√	-	-
					DCM-RL - Door control module rear left	√	√	√	√	√	-	-
					DCM-RR - Door control module rear right	√	√	√	√	√	-	-
					ESA driver - Electric seat adjustment driver(with memory)	√	√	√	√	√	-	-
					ESA passenger - Electric seat adjustment front passenger (with memory)	√	√	√	√	√	-	-
				Air conditioning	AAC - Automatic air conditioning	√	√	√	√	√	-	-
STH - Stationary heater with remote control	√	√	√		√	-	-	-				
Remark: √ means the system has this function -means not												